# Xilinx Zynq FPGA, TI DSP, MCU 기반의 프로그래밍 및 회로 설계 전문가 과정

강사 – Innova Lee(이상훈)

gcccompil3r@gmail.com

학생 – hoseong Lee(이호성)

hslee00001@naver.com

## a. arm assembly



# < arm 어셈블리 함수 >

\*<u>add</u> r3,r1,r2

 $\rightarrow$  r3 = r1+ r2

\* **subgt** r3,r1,r2

 $\rightarrow$  r3= r1-r2

\* **rsble** r3,r1,r2 (reversee subtract)

 $\rightarrow$  r3 =r2 - r1

\* and r3,r1,r2

 $\rightarrow$  r3= r1&r2

\* **biceq** r3,r1,r2

→ r3=r1&~r2

\* **orr** r3.r1.r2

 $\rightarrow$  r3 = r1|r2

\*eors r3,r1,r2 (exclusive or)

 $\rightarrow$  r3 = r1^r2

**\*mov** r1,r2

 $\rightarrow$  r1 = r2

**\*mvn** r1,r2

 $\rightarrow$  r1 = 0xffffffff^r2

**\*cmp** r1,r2

→ r1 - r2 하여 비교후 state flag 업데이트

\*cmn r1,r2 (cmp negative)

→ r1 + r2 하여 비교

산술 명령어 뒤에 접미사 gt ge lt le eq 의미 (status flag상태를 보고 실행할지 말지 결정한다)

gt : great than

ge : great equal //크거나 같다

It : less than

le: less equal // 작거나 같다.

eg : egual // 같다.

ne : not equal

b: byte

산술 명령어 뒤에 접미사 s 가 붙을 경우  $\rightarrow$  산술 처리 결과에 따라 flag 업데이트 한다.

\*\*\*! 느낌표 들어간 문장 이해하기

```
*tsteq r1,r2
→ r1 & r2 하여 비교 후 조건 flag 업데이트
*teq r1,r2
→ r1 ^ r2 하여 비교 후 조건 flag 업데이트
arm 어셈블리 함수 오늘 추가 분
*mov r0, #0xff, 8 : lotation shift
→ arm은 32bit 단위이다. 0Xff = 0x00 00 00 ff
→ 우측 8비트 시프트 시킨다. 0x 00 00 00 00 // 돌아서 상위 비트로 물린다. 즉 0x ff 00 00 00 00
*r1, <a href="lst">lst</a> r2 : logical shift leg
\rightarrow r1 * 2^r2
*r1, asr, r2
\rightarrow r1 / 2^r2
*mul r1,r2,r3
\rightarrow r1 = r2 * r2
*<u>mla</u> r1,r2,r3,r4 : dsp는 곱셈과 덧셈을 동시에 진행 할 수 있다. r2와 r3를 곱하고 거기에 r4를 더해라. <u>이 모두가 1 clock에 끝난다.</u>
\rightarrow r1 = r2 * r3 + r4
```

\*umull r0,r1,r2,r3: Unsigned Long 곱하기, 32 비트 피연산자 및 64 비트 결과  $\rightarrow$  r1 r0 = r2\*r3

\*<u>umlal</u> r0,r1,r2,r3

→ r1 r0 = r2\*r3 + (r0, r1) → r1 = 상위비트 8bit+ r1, r0 = 하위8비트 + r0

```
*ldr r0,[r1,#0x4]: load 레지스터 (reg → mem)
\rightarrow r0 = *(r1 + 4bvte)
*ldreqb_r0,[r1,#0x5]: eq 는 z플래그 확인
\rightarrow r0 = *(r1 + 5 bvte)
*ldr r0, [r1],r2: r1은 주소이다. r2는 byte크기이다.
\rightarrow r0 = *r1, r1 = r1 +r2
*str: store 레지스터 (mem → reg)
*strb r0,[r1] : b는 byte
\rightarrow *r1 = r0
*stmia r0,{r1,r2,r3}: store multiful, r0 memory 에 r1, r2, r3 을 순서대로 집어 넣어라. r0은 포인터(memory)
\rightarrow r0 = r1
*mrs r0 cpsr : cpsr, sqrs의 값을 arm 의 범용 레지스터로 읽어 온다.
→ r0= cpsr, 특수 인터럽트 플래그 비트 레지스터에 접근이 가능하다. msr은 그 반대
*msr cpsr r0 : arm의 값을 cpsr, sqrs 의 레지스터에 쓴다.
→ cpsr = r0, r0값을 cpsr reg로 전달
```

mrs 없으면 cpsr값에 접근할 수 없다. Cpsr레지를 mrs와 같은 별도 명령어로 관리를한다. → 키보드나 마우스를 사용도 인터럽트인데, 사용자가 임의로 cpsr레지를 건드리면 인터럽트 반응이 안되기 때문에 아무나 움직이지 못하도록 운영체제가 관리하는 별도의 instruction을 만들어 둔것.

#### \*어셈블리 사용하는 이유??

하나의 예로 인터럽트 껐다 켰다 하는 것은 운영체제가 한다. 이때 사용하는 프로그래밍은 어셈블리로만 가능하다.

#### \*ldr, \*str

어셈블리어 레벨에서 볼 때 load store register는 핵심이다. load store register 가 존재하는 이유가 뭘까? intel은 memory to memory 연산이 가능하다. arm은 불가능하기 때문에 memory에 있는 정보를 레지스터에 가져오고 다시 메모리에 집어 넣어야 한다. → load는 레지스터에 가져오는 오는 것이고, store는 레지스터에 때려 넣는 것이다. Ok?

#### mov: 같다. 복사

```
#include <stdio.h>

int main(void)
{
    register unsigned int r0 asm("r0") = 0;
    register unsigned int r1 asm("r1") = 0;
    register unsigned int r2 asm("r2") = 0;
    register unsigned int r3 asm("r3") = 0;
    register unsigned int r4 asm("r4") = 0;
    register unsigned int r4 asm("r4") = 0;
    register unsigned int r5 asm("r5") = 0;

    asm volatile("mov r0, #0xff, 8"); // (r0 = (0xff >> 8) = 0xff0000000 → 0xff >> 8 하면 0x00 이 되지만, 사라지는게 아니라 32비트 맨 앞으로 온다고 생각.
    printf("r0 = 0x%x\n",r0);
    return 0;
}
```

lee@lee-Lenovo-YOGA-720-13IKB:~/my\_proj/lhs/lec/5\_1\$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
r0 = 0xff000000

#### Add: 더하기

```
#include <stdio.h>
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register unsigned int r1 asm("r1") = 0;
 register unsigned int r2 asm("r2") = 0;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
 asm volatile("mov r0, \#0xff, 8"); // r0 = 0x ff 00 00 00
 asm volatile("mov r1, \#0xf"); // r1 = 0x 00 00 00 0f
 asm volatile("add r2,r1,r0"); // r2 = r0+r1 = 0x \text{ ff } 00 00 \text{ 0f}
 printf("r2 = 0x\%x\n",r2);
 return 0;
```

```
lee@lee-Lenovo-YOGA-720-13IKB:~/my_proj/lhs/lec/5_1$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
r2 = 0xff00000f
```

#### lsl1: 2^x 승수 곱하기

```
#include <stdio.h>
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register unsigned int r1 asm("r1") = 0;
 register unsigned int r2 asm("r2") = 0;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
 asm volatile("mov r1, #7"); // r1 = 7
 asm volatile("mov r2, #3"); // r2 = 3 // lsl = logical shift leg
 asm volatile("add r0,r1,r2,lsl #7"); // add \frac{r0,r1,r2,lsl \#7}{r} \rightarrow r0 = r1 + (r2 lsl \#7) = 101 + 11 00 00 00 0 = 110000101
 printf("r0 = 0x\%x\n",r0);
 return 0;
```

```
lee@lee-Lenovo-YOGA-720-13IKB:~/my_proj/lhs/lec/5_1$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
r0 = 0x187
```

#### lsl2

```
#include <stdio.h>
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register unsigned int r1 asm("r1") = 0;
 register unsigned int r2 asm("r2") = 0;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
 asm volatile("mov r1, \#7"); // r1 = 7
 asm volatile("mov r2, \#3"); // r2 = 3
 asm volatile("mov r3, #2"); // r3 = 2
 asm volatile("add r0,r1,r2,lsl r3"); // 7+3*2^2 = 19
 printf("r0 = 0x\%x\n",r0);
 return 0;
```

```
lee@lee-Lenovo-YOGA-720-13IKB:~/my_proj/lhs/lec/5_1$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
r0 = 0x13
```

#### lsl3

```
#include <stdio.h>
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register unsigned int r1 asm("r1") = 0;
 register unsigned int r2 asm("r2") = 0;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
 asm volatile("mov r1, #2");
 asm volatile("add r0,r1,r1,lsl #2"); // r0 = 2 + 2 * 2^2 = 10
 printf("r0 = 0x\%x\n",r0);
 return 0;
```

```
lee@lee-Lenovo-YOGA-720-13IKB:~/my_proj/lhs/lec/5_1$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
r0 = 0xa
```

#### asr: 2^x 승수 나누기

```
#include <stdio.h>
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register unsigned int r1 asm("r1") = 0;
 register unsigned int r2 asm("r2") = 0;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
 asm volatile("mov r1, #32");
 asm volatile("add r0,r1,asr #2"); \frac{1}{r0} = 32 / 2^2
 printf("r0 = 0x\%x\n",r0);
 return 0;
```

```
lee@lee-Lenovo-YOGA-720-13IKB:~/my_proj/lhs/lec/5_1$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
r0 = 0x8
```

```
#include <stdio.h>
void show_reg(unsigned int reg)
   int i;
     for(i=31;i>=0;)
           printf("%d",(reg>>i--) & 1);
       printf("\n");
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register unsigned int r1 asm("r1") = 0;
 register unsigned int r2 asm("r2") = 0;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
 asm volatile("mov r1, #32");
 asm volatile("add r0,r1,asr #2"); // r0 = 32 / 2^2 = 8
 asm volatile("mrs r0,cpsr");
 show_reg(r0);
 return 0;
```

: 현재 레지스터들 값이 나온다.
17분

P/t \$cpsr

p/x \$cpsr

n

p r0

p/x r0

mrs 가 하는 역할은 cpsr 레지의 값을 r0레지에 집어넣는 일을 했다. 특수한 레지스터에 접근이 가능하다. 이때 떠올라야 하는 일 : Pushf 와 같다는 것. 스택에 집어 넣는 일과 같은 일을함.)

mrs: 인터럽트를 껐다 켰다 할 때 사용할 수 있음.

(gdb)	si				
22			ı volatile	e("mrs r	),cpsr");
(gdb)	info	reg			
r0			0x8	8	
r1			0x20	32	
r <b>2</b>			0x0	0	
r3			0x0	0	
r <b>4</b>			0x0	0	
r5			0x0	0	
r6			0x10340	66368	
r <b>7</b>			0x0	0	
r8			0x0	0	
r9			0x0	0	
r10			0xf67fe00	00	-159391744
r11			0xf6ffef3	34	-150999244
r12			0xf6ffefb	00	-150999120
sp			0xf6ffef2	28	0xf6ffef28
lr			0xf667cd1	L4	-160969452
oc			0x104f4	0x104f4	<main+40></main+40>
cpsr			0x6000001	LO	1610612752
(gdb)	si				
23		sho	w_reg(r0)	);	
(gdb)	info	reg			
r0			0x6000001	LO	1610612752
r1			0x20	32	
r2			0x0	0	
r3			0x0	0	
r4			0x0	0	
r <b>5</b>			0x0	0	
r6			0x10340	66368	
r7			0x0	0	
r8			0x0	0	
r9			0x0	0	
r10			0xf67fe00	00	-159391744
r11			0xf6ffef3	34	-150999244
r12			0xf6ffefb	00	-150999120
sp			0xf6ffef2	28	0xf6ffef28
lr			0xf667cd1	L <b>4</b>	-160969452
oc			0x104f8	0x104f8	<main+44></main+44>
cpsr			0x6000001	LO	1610612752

#### \*<u>mul</u> : 곱하기 → dsp명령어로 사용

```
#include <stdio.h>
void show_reg(unsigned int reg)
 int i;
 for(i=31;i>=0;)
   printf("%d",(reg>>i--) & 1);
 printf("\n");
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register unsigned int r1 asm("r1") = 0;
 register unsigned int r2 asm("r2") = 0;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
 asm volatile("mov r2, #3");
 asm volatile("mov r3, #7");
 asm volatile("mul r1,r2,r3"); //r1 = r2*r3
 printf("r1 = %d\n", r1);
 return 0;
```

```
lee@lee-Lenovo-YOGA-720-13IKB:~/my_proj/lhs/lec/5_1$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
r1 = 21
```

\*<u>mla</u> : dsp는 곱셈과 덧셈을 동시에 진행 할

수 있다. r2와 r3를 곱하고 거기에 r4를 더해라 → 1 clock에 끝난다.

```
#include <stdio.h>
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register unsigned int r1 asm("r1") = 0;
 register unsigned int r2 asm("r2") = 0;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
 asm volatile("mov r2, #3");
 asm volatile("mov r3, #7");
 asm volatile("mov r4, #33");
 asm volatile("mla r1,r2,r3,r4"); // r1 = r2*r3 + r4
 printf("r1 = \%d\n", r1);
 return 0;
```

lee@lee-Lenovo-YOGA-720-13IKB:~/my\_proj/lhs/lec/5\_1\$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
r1 = 54

\*umull: Unsigned Long 곱하기, 32 비트 피연산자 및 64 비트 결과

```
#include <stdio.h>
void show_reg(unsigned int reg)
 int i;
 for(i=31;i>=0;)
   printf("%d",(reg>>i--) & 1);
 printf("\n");
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register unsigned int r1 asm("r1") = 0;
 register unsigned int r2 asm("r2") = 0;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0; // 0x 00 00 00 ff
 asm volatile("mov r2, \#0x44,8"); //r2 = 0x44 << 8 (00 00 00 00) = 100 0100 00 00 00
 asm volatile("mov r3, \#0x200"); //r3 = 0x200
                                                                       0010 00 00 00 00
 asm volatile("umull r0,r1,r2,r3"); // 32비트인 것을 두개 곱함. 32비트를 넘어가니 두개 r0 r1 레지로 표현한것.
 printf("r1r0 = 0x\%x\%08x\n'',r1,r0);
 return 0;
```

```
}
```

```
lee@lee-Lenovo-YOGA-720-13IKB:~/my_proj/lhs/lec/5_1$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
r1r0 = 0x880
```

\*<u>umlal</u> : mla 는 곱하 고 더하기

```
#include <stdio.h>
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register unsigned int r1 asm("r1") = 0;
 register unsigned int r2 asm("r2") = 0;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
 asm volatile("mov r0, #0xf");
 asm volatile("mov r1, #0x1");
 asm volatile("mov r2, #0x44,8"); //
 asm volatile("mov r3, #0x200");
 asm volatile("umlal r0,r1,r2,r3"); // r1 이 상위 r0이 하위, 즉= 44 *2 = 0x8800 r1은 88+1이고, r0 는 00+f
 printf("r1r0 = 0x\%x\%x\n",r1,r0);
 return 0;
```

lee@lee-Lenovo-YOGA-720-13IKB:~/my\_proj/lhs/lec/5\_1\$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out r1r0 = 0x89f

#### \*<u>ldr</u>: load reg, memory → register

```
#include <stdio.h>
unsigned int arr[5] = {1,2,3,4,5};
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register unsigned int *r1 asm("r1") = NULL;
 register unsigned int *r2 asm("r2") = NULL;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
  r1 = arr; // 배열의 주소값 셋팅
 asm volatile("mov r2, #0x8"); // r2=8
 asm volatile("ldr r0,[r1,r2]"); //[r1,r2] r1은 시작주소이다. r1에서 8바이트 이동하면 3이다, 이제 3 을 r0로 가져오라는 뜻. \
 printf("f0 = %u\n",r0); //r0 오타임.
 return 0;
```

lee@lee-Lenovo-YOGA-720-13IKB:~/my\_proj/lhs/lec/5\_1\$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out f0 = 3

### 

Idr r2, [r1, #12]! @ r1 
$$\leftarrow$$
 r1 + 12 then r2  $\leftarrow$  \*r1

Idr r2, [r0, r1]! @ r0  $\leftarrow$  r0 + r1 then r2  $\leftarrow$  \*r0

Idr r2, [r0, r1, |s| #2]! @ r0  $\leftarrow$  r0 + r1\*4 then r2  $\leftarrow$  \*r0

#### \*ldr2

```
#include <stdio.h>
unsigned int arr[5] = \{1,2,3,4,5\};
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register unsigned int *r1 asm("r1") = NULL;
 register unsigned int *r2 asm("r2") = NULL;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
  r1 = arr; //r1 = arr의 시작주소
 asm volatile("ldr r0,[r1,#0x4]"); // r0 = *(r1 + 4 \text{ byte})
 printf("f0 = \%u\n",r0);
 return 0;
```

```
lee@lee-Lenovo-Y0GA-720-13IKB:~/my_proj/lhs/lec/5_1$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
f0 = 2
```

\*ldreqb: eq 는 z플래그 확인(사실 초기에 z 0으로 초기화 되었기 떄문에 그냥 쓴것 b는 byte임.

```
#include <stdio.h>
char test[] = "HelloARM";
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register char *r1 asm("r1") = NULL;
 register unsigned int *r2 asm("r2") = NULL;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
  r1 = test;
 asm volatile("ldreqb r0,[r1,#0x5]");
 printf("f0 = \%c\n",r0);
 return 0;
```

lee@lee-Lenovo-Y0GA-720-13IKB:~/my\_proj/lhs/lec/5\_1\$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
f0 = A

#### \*strb : ldr의 반대 즉, register→ memory

```
#include <stdio.h>
char test[] = "HelloARM";
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register char *r1 asm("r1") = NULL;
 register unsigned int *r2 asm("r2") = NULL;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
 r1 = &test[5];
 asm volatile("mov r0, #61"); // 61이 ASCII 코드로 = 임.
 asm volatile("strb r0,[r1]"); //*r1 = r0
 printf("test = %s\n",test);
 return 0;
```

```
lee@lee-Lenovo-YOGA-720-13IKB:~/my_proj/lhs/lec/5_1$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
test = Hello=RM
```

#### \*위의 strb과 ldr 비교해보기

```
ldr4.c
#include <stdio.h>
char test[] = "HelloARM";
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register char *r1 asm("r1") = NULL;
 register unsigned int *r2 asm("r2") = NULL;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
 r1 = test;
 asm volatile("mov r2,#0x5");
 asm volatile("ldr r0, [r1,r2]!"); // !가 붙으면, r1에 r2 만큼 이동한 곳에 r1을 픽스 시키라는 뜻이다.
 printf("test = %s, r1 = %s\n",test,r1);
 return 0;
```

lee@lee-Lenovo-YOGA-720-13IKB:~/my\_proj/lhs/lec/5\_1\$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
test = HelloARM, r1 = ARM

#### \*ldr5

```
#include <stdio.h>
unsigned int arr[5] = \{1,2,3,4,5\};
int main(void)
 register unsigned int r0 asm("r0") = 0;
 register unsigned int *r1 asm("r1") = NULL;
 register unsigned int *r2 asm("r2") = NULL;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
 r1 = arr; // r1에는 arr의 시작주소가 들어간다.
 asm volatile("mov r2,#0x4");
 asm volatile("ldr r0, [r1],r2"); // 따로 동작함. r0에는 r1의 시작주소가 들어간다. 즉 1이 들어가는 것이고, r1에는 r1의 4byte지난 것이 들어간다.
 printf("r0 = \%u, r1 = \%u\n",r0,*r1);
 return 0;
```

```
lee@lee-Lenovo-YOGA-720-13IKB:~/my_proj/lhs/lec/5_1$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
r0 = 1, r1 = 2
```

#### \*<u>stmia</u>: reg → mem, stack

```
#include <stdio.h>
int main(void)
 int i;
 unsigned int test_arr[5] = {0};
 register unsigned int *r0 asm("r0") = 0;
 register unsigned int r1 asm("r1") = 0;
 register unsigned int r2 asm("r2") = 0;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
 r0 = test_arr; // r1에는 arr의 시작주소가 들어간다.
 asm volatile("mov r1,#0x3"); // r1=3
 asm volatile("mov r2,r1,lsl #2"); // r2에 r1*2^2 =12
 asm volatile("mov r4, #0x2"); // r4= 2
 asm volatile("add r3,r1,r2,lsl r4"); // r3= 3+ 48 = 51
 asm volatile("stmia r0,{r1,r2,r3}"); // store multiful: store = r0 memory 에 r1, r2, r3 을 순서대로 집어 넣어라.
 for(i=0;i<5;i++)
 printf("test_arr[%d] = %d\n",i,test_arr[i]);
 return 0;
```

```
lee@lee-Lenovo-YOGA-720-13IKB:~/my_proj/lhs/lec/5_1$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
test_arr[0] = 3
test_arr[1] = 12
test_arr[2] = 51
test_arr[3] = 0
test_arr[4] = 0
```

#### \*stmia2:

```
#include <stdio.h> //→ 1 2.3 녹음 30분
int main(void)
 int i;
 unsigned int test_arr[5] = {0};
 register unsigned int *r0 asm("r0") = 0;
 register unsigned int r1 asm("r1") = 0;
 register unsigned int r2 asm("r2") = 0;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
 r0 = test_arr; // r1에는 arr의 시작주소가 들어간다.
 asm volatile("mov r1,#0x3"); // r1=3
 asm volatile("mov r2,r1,lsl #2"); // r2에 r1*2^2 =12
 asm volatile("mov r4, #0x2"); // r4= 48
 asm volatile("add r3,r1,r2,lsl r4"); // r3에 값을 증가 후에 값을 넣어라
 asm volatile("stmia r0!,{r1,r2,r3}"); // store multiful: store = reg 에있는 것을 memory로
 asm volatile("str r4, [r0]");
 for(i=0;i<5;i++)
 printf("test_arr[%d] = %d\n",i,test_arr[i]);
 return 0;
```

```
lee@lee-Lenovo-Y0GA-720-13IKB:~/my_proj/lhs/lec/5_1$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
test_arr[0] = 3
test_arr[1] = 12
test_arr[2] = 51
test_arr[3] = 2
test_arr[4] = 0
```

#### \*stmia2 위와 같은 코드 volatile선언 여러번사용 안함.

```
"stmia r0!,{r1,r2,r3}\n"
    "str r4,[r0]");
for(i=0;i<5;i++)
printf("test_arr[%d] = %d\n",i,test_arr[i]);
return 0;
}
```

```
lee@lee-Lenovo-Y0GA-720-13IKB:~/my_proj/lhs/lec/5_1$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
test_arr[0] = 3
test_arr[1] = 12
test_arr[2] = 51
test_arr[3] = 2
test_arr[4] = 0
```

\*

```
#include <stdio.h>
int main(void)
 int i;
 unsigned int test_arr[5] = {0};
 register unsigned int *r0 asm("r0") = 0;
 register unsigned int r1 asm("r1") = 0;
 register unsigned int r2 asm("r2") = 0;
 register unsigned int r3 asm("r3") = 0;
 register unsigned int r4 asm("r4") = 0;
 register unsigned int r5 asm("r5") = 0;
 register unsigned int r6 asm("r6") = 0;
 r0 = test_arr; // r1에는 arr의 시작주소가 들어간다.
 asm volatile("mov r1,#0x3\n"
        "mov r2,r1,lsl #2\n"
        "mov r4,#0x2\n"
        "add r3,r1,r2,lsl r4\n"
        "stmia r0!,{r1,r2,r3}\n"
        "str r4,[r0]\n"
        "mov r5, #128\n"
        "mov r6,r5,lsl #3\n"
        "stmia r0, {r4,r5,r6}\n"
        "sub r0,r0,#12\n"
        "ldmia r0,{r4,r5,r6}");
 for(i=0;i<7;i++)
```

```
printf("test_arr[%d] = %d\n",i,test_arr[i]);

printf("r4 = %u, r5 = %u, r6 = %u\n",r4,r5,r6);
  return 0;
}
```

```
lee@lee-Lenovo-Y0GA-720-13IKB:~/my_proj/lhs/lec/5_1$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out
test_arr[0] = 3
test_arr[1] = 12
test_arr[2] = 51
test_arr[3] = 2
test_arr[4] = 128
test_arr[5] = 1024
test_arr[6] = 66472
r4 = 3, r5 = 12, r6 = 51
```

: 44분 몇초부터 시작했음…

#### \*func

```
#include <stdio.h>

int my_func(int num)
{
    return num*2;
}

int main(void)
{
    int res, num = 2;
    res = my_func(num);
    printf("res=%d\n",res);
    return 0;
}
```

#### \*func2, 1시간 52 분

```
#include <stdio.h>

int my_func(int n1,int n2,int n3, int n4,int n5)
{
    return n1 + n2 + n3 + n4 + n5;
}

int main(void)
{
    int res, n1 = 2, n2 = 3, n3 = 4, n4 = 5, n5 = 6;
    res = my_func(n1,n2,n3,n4,n5);
    printf("res = %d\n",res);
    return 0;
}
```

lee@lee-Lenovo-YOGA-720-13IKB:~/my\_proj/lhs/lec/5\_1\$ qemu-arm-static -L /usr/arm-linux-gnueabi ./a.out res = 20

R11는 bp 시작주소임

lr 은 복귀주소 2시간 5분

arm , 펌웨어 공업수학 신호처리 dsp fpga

내일은 어셈블리로 시스템콜 써보기.

데이터시트 보는방법 → 이를 토대로 펌웨어 부팅되는 방법.