HDMI EXTENSION BOARD — XEM8310 CONNECTIONS, POWER AND MOUNTING

Power Jack

12 V nominal center-positive

XEM8310 MODULE MOUNTING HOLES

FRONTEND 5 V POWER | CUSTOM MICRO-HDMI PORTS — NOT STANDARD HDMI

USB-C JTAG PROGRAMMER, SELECTION AND FRONTEND PORTS

USB TO JTAG PROGRAMMER

TARGET SELECTION

XEM JTAG MUX, BYPASS

TARGET VOLTAGE CHECK AND ENABLE

XEM JTAG TARGET

1.8 V JTAG TRANSLATOR

XEM8310 unused-pin header holes (VHS; bare holes since V40)

CUSTOM FRONTEND INTERFACE — NOT HDMI VIDEO

FRONTEND PORT A — JTAG SWITCH + MICRO-HDMI

FRONTEND PORT B — JTAG SWITCH + MICRO-HDMI

FRONTEND PORT C — JTAG SWITCH + MICRO-HDMI

FRONTEND PORT D — JTAG SWITCH + MICRO-HDMI

FRONTEND PORT E — JTAG SWITCH + MICRO-HDMI

FRONTEND PORT F — JTAG SWITCH + MICRO-HDMI

FRONTEND PORT G — JTAG SWITCH + MICRO-HDMI

FRONTEND PORT H — JTAG SWITCH + MICRO-HDMI

PCIe x4 — BMR8310 reference circuit

Title	HDMI Extension Board — XEM8310 and USB-C JTAG
Rev	0A