## 指令及其对应机器码查找表

	31:26	25:21	20:16	15:11	10:6	5:0		
	000000	rs	rt	rd	00000	100100	and rd, rs, rt	
逻辑运算指令	000000	rs	rt	rd	00000	100101	or rd,rs,rt	
	000000	rs	rt	rd	00000	100110	xor rd, rs, rt	
	000000	rs	rt	rd	00000	100111	nor rd, rs, rt	
	001100			10	immediate	100111		
		rs	rt				andi rt,rs,immediate	
	001110	rs	rt		immediate		xori rt,rs,immediate	
	001111	00000	rt		immediate		lui rt,immediate	
	001101	rs	rt		immediate		ori rs,rt,immediate	
移位指令	000000	00000	rt	rd	sa	000000	sll rd,rt,sa	
	000000	00000	rt	rd	sa	000010	srl rd,rt,sa	
	000000	00000	rt	rd	sa	000011	sra rd,rt,sa	
	000000	rs	rt	rd	00000	000100	sllv rd,rt,rs	
	000000	rs	rt	rd	00000	000110	srlv rd, rt, rs	
	000000	rs	rt	rd	00000	000111	srav rd,rt,rs	
	000000	00000	1 00000		00000	010000		
数据移动指令	000000	00000	00000	rd	00000	010000	mfhi rd	
	000000	00000	00000	rd 00000	00000	010010 010001	mflo rd mthi rs	
	000000	rs	00000	00000	00000	010001	mtlo rs	
	000000	rs	00000	00000	00000	010011	meto is	
Г	000000	rs	rt	rd	00000	100000	add rd,rs,rt	
算术运算指	000000	rs	rt	rd	00000	100000	addu rd,rs,rt	
	000000	rs	rt	rd	00000	100010	sub rd, rs, rt	
	000000	rs	rt	rd	00000	100011	subu rd,rs,rt	
	000000	rs	rt	rd	00000	101010	slt rd,rs,rt	
	000000	rs	rt	rd	00000	101011	sltu rd, rs, rt	
	000000	rs	rt	00000	00000	011000	mult rs,rt	
	000000	rs	rt	00000	00000	011001	multu rs,rt	
	000000	rs	rt	00000	00000	011010	div rs,rt	
	000000	rs	rt	00000	00000	011011	divu rs,rt	
	001000	rs	rt	immediate			addi rt,rs,immediate	
	001001	rs	rt		immediate		addiu rt,rs,immediate	
	001010	rs	rt		immediate		slti rt,rs,immediate	
	001011 rs rt immediate						sltiu rt,rs,immediate	
	000000		00000	00000	00000	001000	1:	
分支跳转指 令	000000	rs	00000	00000	00000	001000 001001	jr rs	
	000000	rs	00000	rd instr index	00000	001001	jalr rs/jalr rd,rs j target	
	000010					jal target		
	00011	instr_index rs rt offset					beg rs,rt,offset	
	000100	rs	00000	offset			bgtz rs,offset	
	000111	rs	00000	offset			blez rs,offset	
	000101	rs	rt	offset			bne rs,rt,offset	
	000001	rs	00000	offset			bltz rs,offset	
	000001	rs	10000		offset		bltzal rs,offset	
	000001	rs	00001	offset			bgez rs,offset	
	000001	rs	10001		offset		bgezal rs,offset	
访存指令	100000	base	rt		offset		lb rt,offset(base)	
	100100	base	rt		offset		lbu rt,offset(base)	
	100001	base	rt		offset		lh rt,offset(base)	
	100101	base	rt		offset		lhu rt,offset(base)	
	100011	base	rt		offset		lw rt,offset(base)	
	101000	base	rt		offset		sb rt, offset (base)	
	101001	base	rt		offset		sh rt, offset (base)	
101011 base rt offset sw rt,offset(base								
	000000	code 001102				001101	break	
内陷指令	000000		code			001101	syscall	
							Dy Journ	
特权指令	31:26	25:21	20:16	15:11	10:3	2:0		
	010000	00100	rt	rd	00000000	sel	mtc0 rt,rd	
	010000	00000	rt	rd	00000000	sel	mfc0 rt,rd	
	31:26	25		24:6		5:0	1	
	010000	1	0000	00 0000 0000	00 000	011000	eret	
			-					