Centering Guide Installation Instructions

For '72 - '80 MGB Center Console

- 1. Remove the existing plate from the armrest.
- 2. Remove the latch striker from this plate.
- 3. Snap the striker onto the centering guide.
- 4. Attach the centering guide to the armrest.
- 5. Loosen armrest hinge screws slightly and close armrest to test fit. Tighten all screws.





