



A-6 A/T Control System Circuit Diagram (Petrol A/T Model)



A-6 A/T Control System Circuit Diagram (Petrol A/T Model)

(A) With Engine push start system
(B) Without Engine push start system



A-6 A/T Control System Circuit Diagram (Petrol A/T Model)

