



Come leggere i codici dei connettori e i numeri dei terminali

1) Codice connettore / N. terminale / Disposizione terminali

- La forma del connettore e la disposizione dei terminali mostrati in questo manuale sono quelle che si vedono guardando il connettore dalla posizione indicata in figura con "Z".
Fare riferimento a "Connettore".



- L'altezza di alcuni connettori differisce leggermente in base alla fila di terminali. In questo caso, i numeri dei terminali vengono contati in sequenza, partendo dalla fila superiore fino a quella inferiore. Controllare il **numero corretto del terminale** in "Connettore".




NOTA

In alcuni rari casi è possibile trovare connettori aventi i numeri dei terminali impressi, e quindi con una numerazione diversa da quella indicata sopra.

Questo tipo di connettori con i numeri impressi non trova applicazione nel presente manuale.


2) Tipo di connettore



3) Connettore di giunzione (J/C)

- Vari fili diversi con lo stesso colore di filo vengono giuntati su una parte del connettore J/C.


Esempio



4) Giunzione di saldatura (W/S)


- Vari fili diversi con lo stesso colore di filo vengono saldati ad una parte della giunzione W/S.

Esempio






5) Scatola di derivazione (J/B)


Esempio



Circuito interno scatola di derivazione



Disposizione connettori J/B e fusibili



Fuse No.	20
Remarks	ISA

Installed on the cover of the instrument panel.

Function Block Inner Circuit (Detail)

- A/C compressor relay
- ECM
- Fuel pump relay
- Generator
- Glow control
- Ignition coil #1
- Ignition coil #2
- Ignition coil #3
- MAF and IAT sensor
- Brake light switch

Function Block Inner Circuit (Detail)

- A/C charging System Circuit Diagram (Parel model)
- A/C Ignition System Circuit Diagram (C159 model)
- A/C Ignition System Circuit Diagram (C158 model)
- A/C Engine and A/C Control System Circuit Diagram (C158 model)
- A/C Ignition System Circuit Diagram (C158 model)
- A/C Engine and A/C Control System Circuit Diagram (C158 model)
- A/C Ignition System Circuit Diagram (C158 model)
- Immobilizer System Circuit Diagram (Parel model)
- Brake Light System Circuit Diagram

Power Supply Diagram

- Power Supply Diagram (Parel model)
- Power Supply Diagram (C158 model)

Fuse, Junction Block

- Initial Circuit Diagram (See Box No. 20-201)
- Junction Block Inner Circuit Diagram

Connector No.	G2/3
Connector Color	N
Connective position	JIB
Remarks	
wire/harness	G instrument panel harness G instrument panel harness



Location Photo

[Junction Block Inner Circuit Diagram](#)

[Junction Block Connector/Fuse Layout](#)

System Circuit Diagram

- A-1 Cranking System Circuit Diagram(*Bst. model*)
- A-2 Cranking System Circuit Diagram(*Petrol model*)
- A-3 Heater System Circuit Diagram

Connector Layout Diagram

Instrument Panel

- [Wiring Diagram wire/G-instrument panel harness, instrument antenna wire JS-Contact coil H2 model](#)
- [Accessories Diagram \(OCS model\)](#)
- [Wiring Diagram wire/G-instrument panel harness, instrument antenna wire JS-Contact coil H2C model](#)


Power Supply Diagram

- [Power Supply Diagram \(*Petrol model*\)](#)
- [Accessory Diagram \(OCS model\)](#)

Fuse, Junction Block

- [Junction Block JS-Connector/Fuse Layout](#)
- [Junction Block Inner Circuit/Detail](#)

- 6) Posizione, forma e numero di terminali del connettore
 Fare riferimento a "Schema disposizione connettori".
 Fare riferimento a "Schemi elettrici dei sistemi".
 Fare riferimento a "Connettore".



RIFERIMENTI INCROCIATI

"Connettore"

Connector No.	E225
Connector Color	BLK
Connective position	Starting motor relay
Remarks	Petrol model
wire/harness	E:Main harness

1	2
3	4

[Location Photo](#)

System Circuit Diagram

- [Anti Cranking System Circuit Diagram\(Petrol model\)](#)


Connector Layout Diagram

Engine Compartment

- [E:Main harness\(Petrol LHD model\)](#)
- [E:Main harness\(Petrol RHD model\)](#)

Fuse, Junction Block

- [Individual Circuit Fuse Box No.1\(Petrol model\)](#)



E225

"Foto relativa alla posizione"

