

Station Controller Guide (v1.2.1 – 2025-10-16)

Overview

Each Station Controller interfaces with the Main Controller via Ethernet (UDP). It controls local relays, reads inputs, and reports feedback. Optional TM1637 display shows station ID and error status.