Appendix D

CamTool quickstart

This document describes how to capture multiple frames with XIMEA CamTool.

- 1. Download CamTool from Ximea website.
- 2. Run CamTool.
- 3. Go to Edit \rightarrow Options \rightarrow Display \rightarrow Visibility level = Expert or Guru.
- 4. Plug the camera in the computer.
- 5. press ▶ in the top left corner.
- 6. Under Basic on the right-hand side select the Region of Interest if needed.
- 7. Under Basic select the exposure time.
- 8. Under Performance select the output bit depth.
- 9. Input the number of frames desired.
- 10. Go to File \rightarrow Record Time-lapse.
- 11. Set Timing as Freerun.
- 12. Under Output input the save path and file prefix.
- 13. Under Output select the fileformat Flexible Image Transport System (.fits)
- 14. Press Start to start the capture sequence.





Figure D.1: CamTool Main window



 $\textbf{Figure D.2:} \ \textit{CamTool Option window}$




Figure D.3: CamTool Time-lapse window