		PROJECT NAME: <vending< th=""><th>g Machine></th></vending<>	g Machine>			
Test Script Name:						
	User is hungry and would like to					
	urchase a snack from a vending					
	achine. User is presented with a					
	eypad with buttons that correspond to					
	the items available for purchase. There					
	is also an insertion point for paper					
	money and coins. In this scenario, the					
Scenario/Purpose:	user has exact change.					
Prerequisites:	User has viewed and decided which item	to purchase, located at E5.				
Name of Tester:		•	Date:			
	1		Time:			
Step	Description	Expected Results	Pass			
1 Input selection on		Digital display should indicate the				
keypad	Press "E" and then "5"	price of the item selected.				
- 71		Digital display should subtract the				
		amount of each inserted coin or				
		paper money from the total price				
		of the item. Once total is met or				
	Insert paper manay in the hill slat					
2 Ch	Insert paper money in the bill slot	exceeded, the machine will				
2 Submit payment	and/or coins in the coin slot	dispense the item.				
O Delete estimate	User should reach into the tray of Digital display indicates "Item E5					
3 Retrieve item	dispensed items to retrieve the item.	dispensed"				
	*	1				
Test Script Name:	I	PROJECT NAME: <vending< td=""><td>g Machine></td></vending<>	g Machine>			
rest script Name.	-					
	User is hungry and would like to					
	purchase a snack from a vending					
	machine. User is presented with a					
	keypad with buttons that correspond to					
	the items available for purchase. There					
	is also an insertion point for paper					
Scanario/Durnoso	-	money and coins. In this scenario, the				
Scenario/Purpose:	user inserts too much money. User has viewed and decided which item to purchase, located at E5.					
Prerequisites: Name of Tester:	Oser has viewed and decided which item	to purchase, localed at E5.	Date			
varie of Tester:			Date:			
		l	Time:			
Stan	Description	Expected Results	Pass			
Step	Description	Expected Results	1 033			

1 Input selection on		Digital display should indicate the
keypad	Press "E" and then "5"	price of the item selected.
		Digital display should subtract the
		amount of each inserted coin or
		paper money from the total price
		of the item. Once total is met or
	Insert paper money in the bill slot	exceeded, the machine will
2 Submit payment	and/or coins in the coin slot	dispense the item.
	User should reach into the tray of	Digital display indicates "Item E5
3 Retrieve item	dispensed items to retrieve the item.	dispensed"
	User should reach into coin dispenser	Digital display indicates "Please
4 Retrieve change	and retrieve the change.	retrieve your change"

Fail	N/A	Defect/Comments



Fail	N/A	Defect/Comments