Lightning Talk

- Raspberry Pi Zero 網路解決方案

CC (Creative Commons)

姓名標示 一 非商業性 一 相同方式分享



姓名標示 — 你必須給予 適當表彰、提供指向本授權條款的連結,以及 指出(本作品的原始版本)是否已被變更。你可以任何合理方式為前述表彰,但不得以任何方式暗示授權人為你或你的使用方式背書。



非商業性 — 你不得將本素材進行商業目的之使 用。




相同方式分享 — 若你重混、轉換本素材,或依本素材建立新素材,你必須依本素材的授權條款來散布你的貢獻物。



關於台灣樹莓派

• element I 4 指定台灣地區 Raspberry Pi 個人用戶經銷商



http://farnell.com/raspberrypi-consumer/approved-retailers.php?region=apac&MER=MER-LM-OB-RPICC-76315

更多關於台灣樹莓派

- 專注於 Raspberry Pi 應用與推廣
- 舉辦社群聚會/工作坊/讀書會/黑客松
- Website:

- 台灣樹莓派
 Raspberry Pi
- https://www.raspberrypi.com.tw/
- Facebook:
 - 搜尋 RaspberryPi.Taiwan



https://www.facebook.com/RaspberryPi.Taiwan

分享×社群


- COSCUP, MakerConf, PyCon 講者
- 投影片
 - http://www.slideshare.net/raspberrypi-tw/presentations
- 程式碼
 - https://github.com/raspberrypi-tw








Raspberry Pi Zero



硬體規格


- CPU: BCM2835 chipset
 - IGHz ARMII core(40% faster than Raspberry Pi I)
 - 512MB SDRAM
- Storage: MicroSD card
- Power: USB 5V(microUSB)
- Display: Mini-HDMI
- USB: I micro with OTG
- Dimension: 65mm 30mm 5mm

你可能會需要這些東西



https://www.raspberrypi.com.tw/12179/2817/

還可以加上相機模組...






電腦的演進

• 以前的電腦 =>


• 現在的電腦 =>




應用










如果要好用,還是需要有網路吧?

Ethernet


- OTG + USB to RJ45 Converter(H1102NL)



http://www.instructables.com/id/How-to-give-an-internet-access-to-Raspberry-Pi-Zer/

Ethernet

- OTG + USB to RJ45 Converter(SR9800)



http://www.instructables.com/id/How-to-give-an-internet-access-to-Raspberry-Pi-Zer/

Ethernet

- Ethernet Module(ENC28J60)



http://raspi.tv/2015/ethernet-on-pi-zero-how-to-put-an-ethernet-port-on-your-pi


Tethering

- OTG + Sharing Internet connections via USB



http://www.instructables.com/id/How-to-give-an-internet-access-to-Raspberry-Pi-Zer/

WiFi - OTG + WiFi Dongle(RTL8188CUS)



WiFi - Hack WiFi Dongle(RTL8188CUS)



http://hackaday.com/2015/11/28/first-raspberry-pi-zero-hack-piggy-back-wifi/

Speed Testing \$ sudo speedtest-cli

	Download	Upload
Ethernet - OTG + USB to RJ45 Converter(H1102NL)	19.37	2.16
Ethernet - OTG + USB to RJ45 Converter(SR9800)	7.65	4.1
Ethernet - Ethernet Module(ENC28J60)	3.67	3.1
WiFi - OTG + WiFi Dongle(RTL8188CUS)	18.3	4.96
WiFi - Hack WiFi Dongle(RTL8188CUS)	16.5	3.92

單位: Mbit/s

Raspberry Pi Rocks the World

