










Sheet: /Power Management/DCDC_TPS63900_MCU1/
File: DCDC_TPS63900.kicad_sch

Title:


Size: A4

Date:

KiCad E.D.A. 10.0.5

Rev:

Id: 4/10



Sheet: /Power Management/DCDC_TPS63900_MCU2/
File: DCDC_TPS63900.kicad_sch

Title:


Size: A4

Date:

KiCad E.D.A. 10.0.5

Rev:

Id: 5/10



Sheet: /Power Management/DCDC_TPS63900_PERIPH1/
File: DCDC_TPS63900.kicad_sch

Title:


Size: A4

Date:

KiCad E.D.A. 10.0.5

Rev:

Id: 6/10



Sheet: /Power Management/DCDC_TPS63900_PERIPH2/
File: DCDC_TPS63900.kicad_sch

Title:


Size: A4


Date:

KiCad E.D.A. 10.0.5


Rev:

Id: 7/10








SD Card Slot



Speaker





Sheet: /Jumpers/
File: jumpers.kicad_sch

Title:

Size: A4

Date:

KiCad E.D.A. 10.0.5

Rev:

Id: 8/10

