





P	pressure switch	—	trunking
PB	push button		
C	grain flow		
D	under speed		
Z	zero switch		
1/2	limit switches valve		
T	limit switch		
Ho	hoop		
E	rope switch		
G	heater		

1201	BB4	1301	RCC4
1202	BB5	1302	RCC3
1203	BCC1	1303	RCC3H
1204	BCC2	1304	RCC4H
1205	BCC3	1305	RCC4H3
1206	BB6	1306	RCC4H2
1207	BB7	1307	RCC4H1
1208	BB4H	1308	SMC1
1209	BB6H	1309	bin char
1210	BB7H	1310	RBB
1215	BCC1H	1311	RBB
1216	BCC1H2		
1217	BCC2H		
1218	BCC3H		
1219	BCC3H2		
1220	discharge BD1		



problems: cable 249 (new route)
 cable 216, 215, 218
 cable 206
 cable 200
 cable 241 [in existing wiring
 outside]
 CBS for BB4, BB5

Reference: 2871B
 (2863C)