10732
MAIN FUSE SWITCH MFS
INCOMING SUPPLY
L1 L2 L3 N
VOLTMETER FUSES & NEUTRAL LINK VF & VNL
VOLTMETER SELECTOR SWITCH VSS
VOLTMETER
CONTROL SUPPLY SWITCHFUSE
C/O SWITCH
CONTROL POWER RELAY 2
DCE RB2 4,5,7,9.
RUNNING
STOPPED
PULSE AIR UNIT
INTER LOCK RELAY 76.
DCE RC2 13, 14, 16, 17.
INTER LOCK RELAY 53.
D.C.E. RB2
D.C.E. RC2
MF
NEUTRAL LINK NL
MF - MAIN FUSES
IS - ISOLATOR
OL - OVERLOAD
MC - MAIN CONTACTOR
EARTH LEAKAGE TRANSFORMER
EARTH LEAKAGE RELAY ELR
AMMETER
MOTORISED HOIST FEEDER (118, 519, 520, 521)
Nº 114 STARTER FEEDER (TERMS:- 522, 523)
DUST FILTER DRIVE DF7A - (TERMS:- 506, 507A, 508)
ROTARY VALVE RV7A - (TERMS:- 509, 510A, 511)
DUST FAN DF7A (TERMS:- 500, 501A, 502)
DUST FILTER FAN DFF7A (TERMS:- 503, 504A, 505)
PONY MOTOR JL2P (TERMS:- 524, 525A, 526)
OVERLOAD CURRENT TRANSFORMER OLCT
AMMETER CURRENT TRANSFORMER ACT
RECEIVING GRAIN CONVEYOR RCC2 (TERMS:- 512, 513A, 514)
RECEIVING BELT RB2 (TERMS:- 515, 516A, 517)
JUNCTION TOWER ELEVATOR JL2 (TERMS:- 527, 528A, 529)
POWER FACTOR CORRECTION CAPACITORS
SWRM No. 1
PILOT RELAY 58
TIMER 54
MAIN CONTACTOR 54, 56, 62, 63
SLAVE RELAY 67, 68, 72
PRESSURE SWITCH RELAY 53, 69
PRESSURE SWITCH
RUNNING
STOPPED
ISOLATOR RELAY 54, 57
HAND INDICATION
TEST INDICATION
RUNNING INDICATION
STOPPED INDICATION
BLOCKAGE INDICATION
TO DESK
TO DCE/RC2
DC JTX 361 V/16 90-110
RECEIVING CONVEYOR RC2 (Nº 105)
PILOT RELAY 76, 87, 88
TIMER 73
TIMER 77, 79
HORN RELAY 78
MAIN CONTACTOR 73, 75, 83, 84
SLAVE RELAY 129, 135
ISOLATOR RELAY 73, 76
TIMER 89
GRAIN FLOW
TO DCE/RB2
D7-8 JTX 361 V/11 120-142
RECEIVING BELT RB2 (Nº 107)
MAIN CONTACTOR 92, 94, 96
SLAVE RELAY 99, 99, 101, 103
PONY MOTOR JL2P (Nº 103)
F6 JTX 361 V/4 147-158
(NOT USED)
RUNNING INDICATION - TO DESK
FROM MCC 2C
PILOT RELAY 113
TIMER 105
FIRE SUPPRESSION INTERLOCK RELAY 1
MAIN CONTACTOR 108, 111, 53
SLAVE RELAY 118, 119, 124, 135, 105
ISOLATOR RELAY 112, 105
CHUTE BLOCK RELAY 104, 126
TIMER 127
CHOKE ELEVATOR HEAD
CHOKE ELEVATOR BOOT
F7-8 JTX 361 V/17 170-198
JUNCTION TOWER ELEVATOR JL2 (Nº 101)
ROUTE SELECTOR (DESK)
(RB2 BELT RUNNING)
RELAY 133
RELAY 132
TO MCC 9 (MARINE TOWER 2)
TO MCC 1A
LOCAL STOP
DCE RB No. 4 43, 139, 141
PULSE-AIR UNIT No. 4
REVERSE JETTING SWITCH
JUNCTION HOUSE COMPRESSOR No. 2 137, 145.
FIRE VOLT FREE CONTACT
FIRE SUPPRESSION INTERLOCK RELAY 2 104, 147.
INTERLOCK CONTROL CIRCUIT RB No. 4
PLC CABINET
J/H MODULE
HAND RELAY 104
TEST RELAY 104
6

▲ DENOTES CONTACTS MADE IN 'ON' AND 'TEST' POSITIONS.
* DENOTES CONTACTS MADE IN 'TEST' POSITION ONLY
† DENOTES CONTACTS MADE IN 'ON' POSITION ONLY

			REVISION: 13 WIRING MODS FOR FIKES PANEL ON J/HOUSE ELV ADDED. 15/9/03 GO	REVISION: 12 WIRING MODS FROM DUST PLANTS TO D.C.E UNITS ADDED: 27-9-99 GO	REVISION: 11 WIRING MODS. TO CHUTE BLOCK RELAY RELAYS R13 & R14 ADDED. 25-4-94 EP	REVISION: 10 NEW COMPRESSOR FITTED IN JUNCTION HOUSE FOR D.C.E/RB 4 EXTRA COMPRESSOR FITTED ... 92 EP	REVISION: 9 NEW DUST PLANT (DCE) & COMPRESSOR IN J/HOUSE FOR RB No 4 & DCE/RB Nos 3 & 4 5.3.91 EP
REVISION: 8 CONTACT R110/2 ADDED ON LINE 43 9-8-7[illegible]	REVISION: 7 RELAYS R11 & R12 REVERSED ORIGIN: SITE 14/12/72 J.S.	REVISION: 6 CONNECTIONS TO MCC 9B MODIFIED ORIGIN: CUST. 14/2/72 J.S.	REVISION: 5 DESK TERMINALS ~~ADDED~~ ORIGIN: I.C.O. 24/1/72 SGD. J.S.	REVISION: 4 MODS TO RCC2, RB2 AND JL2. ORIGIN: E.I.S.P. 1/6/71 SGD. E.J.C.	REVISION: 3 ON RB2 SUSTAINING CONTACT WAS ON M.C. ORIGIN: / / SGD.	REVISION: 2 BLOCKAGE INDICATION FEED MODIFIED. MINOR MODS. MCC 9B TERMINALS MODIFIED ORIGIN: E.I.S.P. 11/3/71. SGD. J.T.	REVISION: HORN REMOVED ORIGIN: E.I.S.P. 25/2/71 SGD J.T.

DRAWN BY	THOMAS
DATE	18/2/71
CHECKED BY	
APPROVED BY	
DATE	

KEY DIAG. Nº
EXT. DIAG. Nº STX 361 AB
REL. DIAG. Nº JTX 361 AB
PANEL LAYOUT Nº HTX 361 AB

THE DESIGN AND MANUFACTURING INFORMATION CONTAINED IN THIS DRAWING IS THE EXCLUSIVE RIGHT OF DEWHURST & PARTNER LTD. AND MUST NOT BE COPIED OR USED FOR MANUFACTURING PURPOSES.

SCHEME FOR MCC 1B
SEAFORTH GRAIN TERMINAL

ISSUE ~~1~~ ~~2~~ ~~3~~ ~~4~~ ~~5~~ ~~6~~ ~~7~~ ~~8~~ 9 11

DTX 361 AB

DTX 361 AB

...TH GRAIN TERMINAL