10965

EARTH LEAKAGE CURRENT TRANSFORMER

MAIN FUSE SWITCH -MFS

INCOMING SUPPLY L1 L2 L3 N

1L1 1L2 1L3 NN

DENOTES CUSTOMERS INCOMING CABLE

EARTH LINK

DF DISTRIBUTION FUSES

MAIN FUSES -MF

EARTH LEAKAGE RELAY -ELR

ISOLATOR -IS

CONTROL SUPPLY SWITCH FUSE

RELAY R

EARTH TRIP LAMP

TRANSFORMER -CT

SECONDARY FUSES -SF

TO SUBSTATION TRIPPING RELAYS

C/o SWITCH RECTIFIER -MPR

VOLTMETER FUSES AND NEUTRAL LINK -VF AND VNL

VOLTMETER SELECTOR SWITCH - VSS

VOLTMETER

NL

MAIN FUSES -MF

MF AND NEUTRAL LINK -NL

ISOLATOR -IS

MOTORISED HOIST STARTER FEEDER (TERMS. 308 - 311)

MCC6A-C-E FEEDERS (TERMS. 300-303)

MCC6B-D-F FEEDERS (TERMS. 304-307)

M** 603 STARTER FEEDER (TERMS. 312 - 313)

ELRT

EARTH LEAKAGE TRANSFORMER -ELCT

OVERLOAD CURRENT TRANSFORMERS -OLCT OVERLOAD -OL

ACT

MAIN CONTACTOR -MC

PFCC

RECEIVING BELTS: - RB 5 (M** 600) (TERMS. 314, 315A, 316)
- RB 6 (M** 601) (TERMS. 317, 318A, 319)
- RB 7 (M** 602) (TERMS. 320, 321A, 322)

CT1 CT2

CP (CCP)

CONTROL POWER RELAY 2

PILOT RELAY 9, 24, 25, 5, 7

TIMER 5

TIMER 10, 12

HORN RELAY 11

HORNS

MAIN CONTACTOR 16, 17

SLAVE RELAY 22, 23, 24, 26

ROPE SWITCH RELAY 4, 27

HOURS COUNTER

RUNNING

STOPPED

ISOLATOR RELAY 5, 8, 26

FROM MCC 2C

FROM MCC 3B

FROM TRIPPER RELAY PANEL

(8 OFF) ROPE SWITCHES

TO RB6&7

HAND INDICATION

TEST INDICATION

RUNNING INDICATION

STOPPED INDICATION

TO DESK

TO MCC 3B - TH1

TO MCC 3B - TH2

TO MCC 3A - DCC1

TO MCC 3B - DCCV1

TO MCC 3B - TRB5

RECEIVING BELT RB5 (M*600)

D3-4 JTX361V/22

1 - 38 40-44

PILOT RELAY 35, 49, 50, 31, 32

TIMER 31

TIMER 36, 38

HORN RELAY 37

MAIN CONTACTOR 42, 43

SLAVE RELAY 47, 48, 49, 51, 53

ROPE SWITCH RELAY 30, 52

ISOLATOR RELAY 31, 34, 51

TO MCC 3B - TH2

TO MCC 3B - TH3

TO MCC 3A - DCC1

TO MCC 3B - DCCV2

TO MCC 3B - TRB6

TO MCC 3B - TH4

RECEIVING BELT RB6 (M*601)

D5-6 JTX361V/22

50 - 80 82 - 88

PILOT RELAY 60, 74, 75, 56, 58

TIMER 56

TIMER 61, 63

HORN RELAY 62

MAIN CONTACTOR 67, 68

SLAVE RELAY 72, 73, 74, 76

ROPE SWITCH RELAY 55, 77

ISOLATOR RELAY 56, 59, 76

TO MCC 3B - TH3

TO MCC 3B - TH4

TO MCC 3A - DCC1

TO MCC 3B - DCCV3

TO MCC 3B - TRB7

RECEIVING BELT RB7 (M*602)

D7-8 JTX361V/22

90 - 120 122 - 126

* CONTACTS SHOWN THUS ARE MADE IN 'TEST' POSITION ONLY

+ CONTACTS SHOWN THUS ARE MADE IN 'ON' POSITION ONLY

▲ CONTACTS SHOWN THUS ARE MADE IN 'TEST' AND 'ON' POSITIONS

10965

SCHEMATIC DIAGRAM FOR MCC6
SEAFORTH GRAIN TERMINAL

DEWHURST & PARTNER LTD.
MELBOURNE WORKS HOUNSLOW

SCHEMATIC DIAGRAM FOR MCC6 — SEAFORTH GRAIN TERMINAL

REVISION 7	REVISION 6	REVISION 5	REVISION 4
PR1 PR2 PR3 LINE Nos CORRECTED.	WIRE MARKERS 2L1,2L3 ADDED TO DF.	SUSTAINING CONTACTS WERE ON MC.	MCC 2C CONTACTS MODIFIED. HORN CIRCUITS MODIFIED
ORIGIN. TEST 6·5·71 JT	ORIGIN. EISP. 28·4·71 JT	ORIGIN. EISP. 20·4·71 JT	ORIGIN. EISP. 5·3·71 JT

REVISION 12	REVISION 11	REVISION 10	REVISION 9	REVISION 8
MODIFICATIONS TO TRIPPER TROLLEY BOARD AND TRIPPER AT STATION. RELAYS ADDED. 14·10·71 JT	CBR1-2&3 NOW N/C	CONTACTS ON R59, R72 DESK RBS ON MCC 3B WERE N/O	DESK TERMINALS ADDED	MODS TO MCC 3A-DCC1 INTERLOCKS SLAVE RELAYS NOW SWITCHED BY M.C.
ORIGIN. EISP. 17·2·71 JT	ORIGIN ICD 2·11·73 THP	ORIGIN ICD 22·1·72 JS	ORIGIN ICD 7·2·72 JS	

REVISION 3	REVISION 2	REVISION 1
DISTRIBUTION FUSES AND EARTH LINK ADDED.	MINOR MODS.	INCOMING EARTH LEAKAGE ADDED.
ORIGIN. EISP. 17·2·71 JT	ORIGIN. EISP. 12·2·71 JT	ORIGIN EISP 8·2·71 BJC

THE DESIGN & MANUFACTURING INFORMATION CONTAINED IN THIS DRG. IS THE EXCLUSIVE RIGHT OF DEWHURST & PARTNER LTD. & MUST NOT BE COPIED OR USED FOR MANUFACTURING PURPOSES

ISSUE 12

DTX361Z

DRAWN BY J.M.B.
DATE 27·1·71
CHECKED BY
APPROVED BY
DATE

KEY DIAG. No.
EXT DIAG. No. RTX361Z
REL. DIAG. No.
PANEL LAYOUT No. GTX361Z

DTX361Z