尺寸:140x100mm 材质:128G铜板纸,单色印刷,折叠页



产品品牌: FEKER
产品名称: ALICE98
产品结构: Gasket结构
产品尺寸: 435.7\*156.6\*43.5mm
产品重量: ≈ 970 g
按键数量: 98Key
连接方式: 有线-USB
线材长度: ≈1.5M
接 口: 键线分离式typec接口

矩 阵:全键无冲

背 光:全彩RGB 兼 容 性:Windows7/8/9/10/11/Mac/Linux

Product brand: : FEKER Product Name: ALICE98


Product structure: gasket structure Product size: 435.7\*156.6\*43.5mm Product weight: ≈970g


Number of keys: 98Key

Connection method: Wired-USB Wire length: ≈1.5M

Interface: Keywire separation type C interface Matrix: Full key no impact

Backlight: Full color RGB, 19 sets of lighting effects Compatibility: Windows7/8/9/10/11/Mac/Linux





# 开关/指示灯说明

1.CAPS指示灯:CAPS键指示灯白光指示

**2.锁win指示灯:** WIN键白光指示 **3.Num指示灯:** NUM键白光指示

## 灯光效果说明

1、上电后,灯光围绕键盘跑动,拖尾熄灭,跑完所有按键后,恢复掉电前灯光状态。 2、灯光模式的点亮顺序依表格从上到下,最后切完模式后有OFF。

3、灯光效果,46组灯效

## 旋钮功能说明

Key compound function description





组合按键 WIN功能 MAC功能(单按触发)

FN+F1	此电脑	屏幕亮度减		
FN+F2	主页	屏幕亮度加		
FN+F3	计算器	多任务控制器		
FN+F4	邮箱	程序列表		
FN+F5	播放器	无	拨动开关选择MAC / WIN	
FN+F6	停止播放	无		
FN+F7	上一曲	上一曲		
FN+F8	播放/暂停	播放暂停		
FN+F9	下一曲	下一曲		
FN+F10	静音	静音		
FN+F11	音量-	音量-		
FN+F12	音量+	音量+		
N+BACK	短按一下复位	短按一下复位	键盘背光灭一次表示	
FN+ \	键盘背光颜色切换	键盘背光颜色切换	顺序:单色循环渐变	
N+Enter	键盘背光灯效切换	键盘背光灯效切换	46种灯效,默认随波逐流	

组合按键	WIN功能	MAC功能(单按触发)	描述	
FN+右Shift	切换指示灯灯效	切换指示灯灯效	流光/光谱/呼吸/常亮/灭 默认流光	
FN+*(Num)	切换旋钮装饰条灯效	切换旋钮装饰条灯效	流光/光谱/呼吸/常亮/灭 默认流光	
FN+T	键盘背光开关	键盘背光开关	带记忆	
FN+WIN-L	锁WIN	无	无	
FN+→	灯光速度变慢	灯光速度变慢		
FN+←	灯光速度加快	灯光速度加快		
FN+↑	灯光亮度+	灯光亮度+	极限档位时上下左右灯闪烁3次指示	
FN+↓	灯光亮度-	灯光亮度-		
FN+DEL	INS	INS		
FN+PGUP	номе	HOME		
FFN+PGDN	END	END		

1. CAPS indicator light: CAPS key indicator light is indicated by white light

2. Lock win indicator: WIN key indicates white light.

### 3.NUM indicator: Num key indicates white light. ghting effect description


1. After power-on, the light runs around the keyboard, and the tail goes out. After running all the keys, the light status before power-off is restored.


2. Lighting mode lighting order according to the table from top to bottom, finally cut the mode after OFF.

## Knob Function Description

3.46 sets of lighting effects

Roller default: press to mute/left V-/right V+





e down	_		
<u></u>			

ination buttons	WIN function	MAC function (single press trigger)	Describe	Combin
FN+F1	This computer	Screen brightness decrease		F
FN+F2	Homepage	Screen brightness increase		
FN+F3	Calculator	Multi task controller		FN
FN+F4	Mailbox	Program List		
FN+F5	Player	Nothing	Flip the switch to select MAC/WIN	
FN+F6	Stop playing	Nothing		
FN+F7	Previous song	Previous song		FI
FN+F8	Play/Pause	Play pause		
FN+F9	Next song	Next song		
N+F10	Mute	Mute		
N+F11	Volume -	Volume -		
N+F12	Volume+	Volume +		
BACKSPACE	Short press to	Short press to reset.	Keyboard backlight goes out once.	
	reset.			
	Keyboard	Keyboard backlight color		
FN+ \	backlight color	switching	Order: Monochrome Cyclic Gradient	
	switching			

be	Combination buttons	WIN function
	FN+Enter	Keyboard backlig effect switching
	FN+*(NUM)	Switching knob d rative strip lamp
IAC/WIN	FN+T	Keyboard backlig switch
	FN+WIN-L	Lock WIN
	FN+→	Light speed slows
	FN+←	Accelerated ligh
out once.	FN+↑	Light brightness
ic Gradient	FN+↓	Light brightness

	Combination buttons	WIN function	МА
	FN+Enter	Keyboard backlight	Ke
		effect switching	
	FN+*(NUM)	Switching knob deco	Key
		rative strip lamp effect	
	FN+T	Keyboard backlight	
	1 14 1	switch	
	FN+WIN-L	LL-WIN	
		Lock WIN	Lig
	FN+→	Light speed slows	Aco
		down	
	FN+←	Accelerated lighting	Ac
_		speed	sp
	FN+↑	Light brightness+	Lig
_	FN+↓	Light brightness-	Lig
			ľ

е				effe
			FN+*(NUM)	Swi
				rati
	Flip the switch to select MAC/WIN		FN+T	Key
			11111	swi
			FN+WIN-L	
				Loc
			FN+→	Ligi
				dov
			FN+←	Acc
		╛╽╽		spe
	Vaubaard baaklight good aut anga			

# Accelerated lighting + Light brightness+ down, left, and right lights flash three times Light brightness-

			. '		
unction	MAC function (single press trigger)	Describe			
l backlight	Keyboard backlight effect switching	46 lighting effects, default to follow the flow		٦	
tching					Comb
g knob deco	Keyboard backlight switch	Streamer/Spectrum/Breathing/Always		-	
p lamp effect		On/Off Default Streamer			
lbacklight					

Light speed slows down With memory Accelerated lighting speed When in the extreme gear position, the up,

to indicate

tunction (single press trigger)	Describe		
board backlight effect switching	46 lighting effects, default to follow the flow	Combination buttons	W
board backlight switch	Streamer/Spectrum/Breathing/Always	FN+DEL	
	On/Off Default Streamer	FN+PGUP	
		FN+PGDN	

感谢您对FEKER产品的信任和支持,为了让您放心使用产品,更好的保证您的权益。 我司将严格遵守并执行相关规定,实行售后。 WIN function MAC function (single press trigger) Describe 1、服务有效期: 自购买之日起质量保证12个月,终生维护,配件不在保修范围内; 2、服务内容:按微型计算机商品维修更换退货责任规定进行服务; 3、不属于服务范围:

> a.已超出有效服务或免费维修期的; b.未按照正确说明使用、维护、保管导致故障或损坏的; c.由于不可抗力(如自然灾害等)原因造成的产品之不良; 更多产品信息请关注 d.人为因素导致产品不良(如操作失误,磕碰,进水,输入不合适电压等);

FEKER官网: e.一切人为损坏、自行拆机、拆封标、使用不当等,不在保修范围。 https://www.fekergaming.com

### \_\_\_\_ 产品型号:\_\_\_\_\_

购买日期:\_\_\_\_\_ 客户姓名: \_\_\_\_\_ 联系电话:\_\_\_\_\_