Electronic Wiring Diagram

Ground No. (Wire Color)	Harness	Component Name	Component Location	Schematic
G1	12 Volt	Component Name	Engine Compartment > Ground	Charging System
(BLK)	Battery Ground Cable	 12 Volt Battery Sensor 	Cable	Energy Management System
				Ground Cable
	_			Power Supply
G2 (BLK)	Engine Ground Cable	• Engine	Engine Compartment > Ground Cable	Ground Cable
G3 (BLK)	Transmission Ground Cable	Transmission Housing	Engine Compartment > Ground Cable	Ground Cable
T7 (BLK)	Cable Reel	a Cabla Baal	Dashboard > Steering	Cable Reel
	Subharness	Cable Reel		Horns
G101	Engine Wire		Engine Compartment > Engine	Ignition System
(BLK)	Harness	No. 1 Ignition CoilNo. 2 Ignition Coil	(Mission)	PCM (All)
		No. 3 Ignition Coil		VTEC/VTC System
		No. 4 Ignition Coil		VIEO, VIO Gystem
		 Thermal Joint 4 		
		Thermal Joint 3		
G101	Engine Wire Harness	a Thomas Isiat 2	Engine Compartment > Engine	Ignition System
(BLK)		Thermal Joint 3VTC Oil Control	(Mission)	PCM (All)
		Solenoid Valve B		VTEC/VTC System
		 Rocker Arm Oil Pressure Switch 		
		VTC Oil Control Solenoid Valve A		
		Rocker Arm Oil Control Solenoid		
G301	Engine	DOM	Engine Compartment > Left Side >	PCM (All)
(BLK)	Compartment Wire Harness	• PCM	Location Engine Compartment > Left Side > Detail 1	PCM Power and Ground
G301	Engine Compartment Wire Harness		Engine Compartment > Left Side > Location Engine Compartment > Left Side > Detail 1	PCM (All)
(BLK)				PCM Power and Ground
				PGM-FI System
G301 (BLK)	Engine Compartment Wire Harness	Left Front Parking/Daytime Running Light	Engine Compartment > Left Side > Location Engine Compartment > Left Side > Detail 1	License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights
G301 (BLK)	Engine Compartment Wire Harness	Left Front Side Marker Light	Engine Compartment > Left Side > Location Engine Compartment > Left Side > Detail 1	License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights
G301	Engine Compartment Wire Harness	rtment • Left Fog Light	Engine Compartment > Left Side > Location Engine Compartment > Left Side > Detail 1	Fog Lights
(BLK)				Keyless/Power Door Locks/Security System
_				License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights

Ground No. (Wire Color)	Harness	Component Name	Component Location	Schematic
G301			Engine Compartment > Left Side >	
(BRN)	Engine Compartment Wire Harness	Left Headlight	Location Engine Compartment > Left Side > Detail 1	Keyless/Power Door Locks/Security System
G302 (BLK)	Engine Compartment Wire Harness	Windshield Wiper Control Unit/Motor	Engine Compartment > Right Side > Location Engine Compartment > Right Side > Detail 1	Wiper/Washer (Windshield)
G302 (BLK)	Engine Compartment Wire Harness	Right Front Side Marker Light		License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights
G302	Engine	- Desire Florid Level	> Location Engine Compartment > =	Gauges
(BLK)	 Compartment Wire Harness 	 Brake Fluid Level Switch 		Keyless Access System
	_	Clutch Pedal Position Switch A		PCM (All)
	_	Position SwitchA		PGM-FI System
	_			Starting System
	_			VSA/TPMS (Tire Pressure Monitoring System)
G302	Engine	B: 1/5 1: 1/	Engine Compartment > Right Side	Fog Lights
(BLK)	 Compartment Wire Harness 	Right Fog LightRight Headlight	I l	Keyless/Power Door Locks/Security System
	_			License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights
G302	Engine	Right Headlight	Engine Compartment > Right Side	Headlights
(BRN)	Compartment Wire Harness	- ragnit rieddiigni	Location Engine Compartment > Right Side > Detail 1	Keyless/Power Door Locks/Security System
G302 (GRY)	Engine Compartment Wire Harness	Right Front Parking/Daytime Running Light	Engine Compartment > Right Side > Location Engine Compartment > Right Side > Detail 1	License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights
G303 (BLK)	Engine Compartment Wire Harness	VSA Modulator- Control Unit	Engine Compartment > Right Side > Location Engine Compartment > Right Side > Detail 1	VSA/TPMS (Tire Pressure Monitoring System)
G304 (BLK)	Engine Compartment Wire Harness	EPS Control Unit	Engine Compartment > Right Side > Location Engine Compartment > Right Side > Detail 1	EPS
G305	Engine — Compartment Wire Harness	\A/I	Dashboard > Dashboard (Engine Compartment Wire Harness)	Climate Control
(BLK)				Wiper/Washer (Rear Window)
				Wiper/Washer (Windshield)
G305 (BLK)	Engine Compartment Wire Harness	Power Transistor	Dashboard > Dashboard (Engine Compartment Wire Harness)	Climate Control
G305	Engine Compartment Wire Harness	Under-Dash Fuse/Relay BoxFan Control Relay	Dashboard > Dashboard (Engine Compartment Wire Harness)	Accessory Power Sockets
(BLK)				Climate Control
				Fans
				Keyless/Power Door Locks/Security System
G401	Front End	Horn (Low)	Engine Compartment > Left Side >	Horns
(BLK)	Wire Harness	• Horn (High)	Location	Keyless/Power Door Locks/Security System
G401	Front End Wire Harness	- A/C Candanaa	Engine Compartment > Left Side > Location	Climate Control
(BLK)				Fans

Ground No. (Wire Color)	Harness	Component Name	Component Location	Schematic
G401 (BRN)	Front End Wire Harness	Hood Latch Switch	Engine Compartment > Left Side > Location	Keyless/Power Door Locks/Security System
G501	Dashboard	Body Control	Dashboard > Dashboard Main	Keyless Access System
(BLK)	Wire Harness	Module	(Left Side) > Location	Wiper/Washer (Rear Window)
G501	Dashboard	VSA OFF Switch	Dashboard > Dashboard Main (Left Side) > Location	Gauges
(BLK)	Wire Harness	vortor ounion		VSA/TPMS (Tire Pressure Monitoring System)
G501	Dashboard	Driver's Door Lock	Dashboard > Dashboard Main (Left Side) > Location	Entry Light Control System and Ignition Key Light
(BLK)	Wire Harness	Actuator/Knob		Keyless Access System
		Switch/Key Cylinder Switch		Keyless/Power Door Locks/Security System
		Driver's Power Window Maken		Power Mirrors
		Window MotorDriver's Door Outer		Power Windows
	_	Handle Power Window Master Switch Power Mirror Switch		Rear Window/Power Mirror Defoggers
G501 (BLK)	Dashboard Wire Harness	Data Link Connector (DLC)	Dashboard > Dashboard Main (Left Side) > Location	DLC
G501	Dashboard Wire Harness	Body Control Module	Dashboard > Dashboard Main (Left Side) > Location	Cruise Control
(BLK)				Fans
				Fog Lights
				Fuel Supply System
				Idle Control System
	_			Keyless Access System
	_			Keyless/Power Door Locks/Security System
				License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights
				Low Oil Pressure Indicator, Reminder Systems, Safety Indicator
				Power, Grounds and Diagnostics
	_			Starting System
	_			Wiper/Washer (Rear Window)
G501 (BLK)	Dashboard Wire Harness	Gauge Control Module	Dashboard > Dashboard Main (Left Side) > Location	Ambient Lights, Cargo Area Lights, Ceiling Lights, Console Lights, Courtesy Lights, Footwell Lights, Glove Box Lights, Individual MAP Lights, Trunk Lights and Vanity Mirror Lights
	_			Cruise Control
-	_			Dashlights
				Gauges
				Telematics/HandsFreeLink System
				MIL Circuit
				Navigation System

Ground No. (Wire Color)	Harness	Component Name	Component Location	Schematic
	Dashboard	Component Name	•	
G501 (BLK)	Wire Harness	Under-Dash Fund / Policy Pay	Dashboard > Dashboard Main (Left Side) > Location	Accessory Power Sockets
	_	Fuse/Relay Box		Climate Control
0500	Daalahaasid		Death and S Death and Main	Keyless/Power Door Locks/Security System
G502 (BLK)	Dashboard Wire Harness	Power Window	Dashboard > Dashboard Main (Left Side) > Location	Keyless/Power Door Locks/Security System
	_	Master Switch		Power Mirrors
	_			Power Windows
				Rear Window/Power Mirror Defoggers
G502 (BLK)	Dashboard Wire Harness	 Automatic Brake Hold Switch Electric Parking Brake Switch Integrated Drive- Mode Switch 	Dashboard > Dashboard Main (Left Side) > Location	Gauges
, ,			(201.0100) 20041101	VSA/TPMS (Tire Pressure Monitoring System)
G502	Dashboard		Dashboard > Dashboard Main (Left Side) > Location	Cable Reel
(BLK)	Wire Harness	Cable Reel		Dashlights
	_			Gauges
	_			Telematics/HandsFreeLink System
	_			Horns
	_			Navigation System
G502 (BLK)	Dashboard Wire Harness	Duly and March	Dashboard > Dashboard Main (Left Side) > Location	Ambient Lights, Cargo Area Lights, Ceiling Lights, Console Lights, Courtesy Lights, Footwell Lights, Glove Box Lights, Individual MAP Lights, Trunk Lights and Vanity Mirror Lights
				Entry Light Control System and Ignition Key Light
G503 (BRN)	Dashboard Wire Harness	Hazard Warning Switch	Dashboard > Dashboard Main (Left Side) > Location	License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights
G503	Dashboard		Dashboard > Dashboard Main	Keyless Access System
(BRN)	Wire Harness	 Engine Start/Stop Switch 	(Left Side) > Location	Starting System
G503 (BRN)	Dashboard Wire Harness	Automatic Lighting Control Unit- Sensor	Dashboard > Dashboard Main (Left Side) > Location	Headlights
G503	Dashboard		Dashboard > Dashboard Main (Left Side) > Location	Climate Control
(BRN)	— Wire Harness	Climate Control Panel		Rear Window/Power Mirror Defoggers
G504 (BLK)	Dashboard Wire Harness	Stereo Amplifier	Dashboard > Dashboard Main (Right Side) > Location	Telematics/HandsFreeLink System
(==:\)	vviie i lailless	•	(raght Olde) > Location	Navigation System
G504 (BLK)	Dashboard — Wire Harness —	Audio-Navigation UnitCenter Display Unit	Dashboard > Dashboard Main (Right Side) > Location	Dashlights
(BLIV)				Telematics/HandsFreeLink System
				Navigation System
G505	Dashboard	Front Passenger's Power Window	Dashboard > Dashboard Main (Right Side) > Location	Keyless/Power Door Locks/Security System
(BLK)	Wire Harness			Power Mirrors
	_	Switch		Power Windows
	_			

Ground No. (Wire Color)	Harness	Component Name	Component Location	Schematic
Colory	Harriess	Component Name	Component Location	Rear Window/Power Mirror Defoggers
G505 (BLK)	Dashboard Wire Harness	Electric Steering Lock	Dashboard > Dashboard Main (Right Side) > Location	Keyless Access System
G505	Dashboard	Climate Control	Dashboard > Dashboard Main	Climate Control
(BLK)	Wire Harness	Unit	(Right Side) > Location	Rear Window/Power Mirror Defoggers
G505 (BLK)	Dashboard Wire Harness	Front Accessory Power Socket	Dashboard > Dashboard Main (Right Side) > Location	Accessory Power Sockets
G505	Dashboard	Front Passenger's	Dashboard > Dashboard Main	Keyless Access System
(GRY)	— Wire Harness	Door Lock Actuator/Knob Switch Front Passenger's Door Outer Handle	(Right Side) > Location	Keyless/Power Door Locks/Security System
G506 (BLK)	Dashboard Wire Harness	SRS Unit	Dashboard > Dashboard (Console)	SRS
G601 (BLK)	Floor Wire Harness	Driver's Seat Position Sensor	Body > Floor (Front)	SRS
G601 (BLK)	Floor Wire Harness	Left Rear Power Window Switch	Body > Floor (Front)	Power Windows
G601	Floor Wire	Floor Wire Harness • Driver's Seat Belt Buckle Switch	Body > Floor (Front)	Low Oil Pressure Indicator, Reminder Systems, Safety Indicator
(BLK)	- Harness			SRS
G601 (BLK)	Floor Wire Harness	Left Rear Door Lock Actuator/Knob Switch	Body > Floor (Front)	Keyless/Power Door Locks/Security System
G601	Floor Wire	a Fuel Teak Linit	Body > Floor (Front)	Fuel Supply System
(BLK)	— Harness	 Fuel Tank Unit 		PCM (All)
	_			PGM-FI System
G602 (BRN)	Floor Wire Harness	Right Rear Power Window Switch	Body > Floor (Front)	Power Windows
G602	Floor Wire	• Front December's	Body > Floor (Front)	Low Oil Pressure Indicator, Reminder Systems, Safety Indicator
(BRN)	- Harness	 Front Passenger's Seat Belt Buckle Switch 		SRS
G602 (BRN)	Floor Wire Harness	Right Rear Door Lock Actuator/Knob Switch	Body > Floor (Front)	Keyless/Power Door Locks/Security System
G603	Floor Wire Harness	re	Body > Floor (Left Rear)	Rear Window/Power Mirror Defoggers
		Rear Window DefoggerRear Window Wiper Motor		Wiper/Washer (Rear Window)

Ground No. (Wire Color)	Harness	Component Name	Component Location	Schematic
G603	Floor Wire	Left Inner TaillightRight Inner TaillightHigh Mount Brake Light	Body > Floor (Left Rear)	Brake Lights
(BLK)	— Harness			License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights
G603	Floor Wire Harness		Body > Floor (Left Rear)	Back-Up Lights
(BLK)		Left TaillightLeft Brake Light		Brake Lights
		Left Rear Turn		Keyless/Power Door Locks/Security System
	ŭ	Signal Light • Left Back-Up Light		License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights
G603 (BLK)	Floor Wire Harness Tailgate Latch Tailgate Outer Handle/Lock Switch/License Plate Light	Tailgate Outer	Body > Floor (Left Rear)	Ambient Lights, Cargo Area Lights, Ceiling Lights, Console Lights, Courtesy Lights, Footwell Lights, Glove Box Lights, Individual MAP Lights, Trunk Lights and Vanity Mirror Lights
				Keyless Access System
			Keyless/Power Door Locks/Security System	
				License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights
				Low Oil Pressure Indicator, Reminder Systems, Safety Indicator
G603 (BLK)	Floor Wire Harness	 Adaptive Damper Control Unit 	Body > Floor (Left Rear)	Adaptive Damper System
G604	Floor Wire	Keyless Buzzer	Body > Tailgate	Keyless Access System
(BLK)	Harness			Keyless/Power Door Locks/Security System
G604	Floor Wire Harness Right Taillight Right Brake Light Right Rear Turn Signal Light Right Back-Up Light	0 0	Body > Tailgate	Back-Up Lights
(BLK)				Brake Lights
		<u> </u>		Keyless/Power Door Locks/Security System
		Right Back-Up		License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights