# **PRODEMAND**

2017 Honda Civic 2.0L Eng Type R

Print Date: 9/19/2017

## Service Manual: HONDA WHEEL ALIGNMENT SPECIFICATIONS

#### WHEEL ALIGNMENT SPECIFICATIONS > CIVIC

CIVIC 2/4 Door Except Si Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	4.68	5.28	5.88
Right Front Caster (°)	4.68	5.28	5.88
Left Front Camber (°)	-0.8	-0.3	0.2
Right Front Camber (°)	-0.8	-0.3	0.2
Front Toe (°)	-0.17	0	0.17
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.95	-1.2	-0.45
Right Rear Camber (°)	-1.95	-1.2	-0.45
Rear Toe (°)	0.08	0.17	0.33
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	38.1	40.1
Left Max Turn, Inward (°)	42.1	38.1	40.1
Right Max Turn, Inward (°)	42.1	32	33
Left Max Turn, Outward (°)	34	32	33
Right Max Turn, Outward (°)	34	-	-

CIVIC 5 Door Except Type R with 18 in. wheels

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	4.8	5.3	5.8
Right Front Caster (°)	4.8	5.3	5.8
Left Front Camber (°)	-0.8	-0.3	0.2
Right Front Camber (°)	-0.8	-0.3	0.2
Front Toe (°)	-0.17	0	0.17
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.95	-1.2	-0.45
Right Rear Camber (°)	-1.95	-1.2	-0.45
Rear Toe (°)	0.08	0.17	0.33
Thrust Angle	0	0	0

Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	35.03	37.03
Left Max Turn, Inward (°)	39.03	35.03	37.03
Right Max Turn, Inward (°)	39.03	30.27	31.27
Left Max Turn, Outward (°)	32.27	30.27	31.27
Right Max Turn, Outward (°)	32.27	-	-

CIVIC 5 Door Except Type R without 18" wheels

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	4.8	5.3	5.8
Right Front Caster (°)	4.8	5.3	5.8
Left Front Camber (°)	-0.8	-0.3	0.2
Right Front Camber (°)	-0.8	-0.3	0.2
Front Toe (°)	-0.17	0	0.17
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.95	-1.2	-0.45
Right Rear Camber (°)	-1.95	-1.2	-0.45
Rear Toe (°)	0.08	0.17	0.33
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	38.07	40.07
Left Max Turn, Inward (°)	42.07	38.07	40.07
Right Max Turn, Inward (°)	42.07	32.02	33.02
Left Max Turn, Outward (°)	34.02	32.02	33.02
Right Max Turn, Outward (°)	34.02	-	-

#### CIVIC Si Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	4.9	5.4	5.9
Right Front Caster (°)	4.9	5.4	5.9
Left Front Camber (°)	-0.83	-0.33	0.17
Right Front Camber (°)	-0.83	-0.33	0.17
Front Toe (°)	-0.17	0	0.17

Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.08	-0.33	0.42
Right Rear Camber (°)	-1.08	-0.33	0.42
Rear Toe (°)	0.08	0.17	0.33
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	34.88	36.88
Left Max Turn, Inward (°)	38.88	34.88	36.88
Right Max Turn, Inward (°)	38.88	30.13	31.13
Left Max Turn, Outward (°)	32.13	30.13	31.13
Right Max Turn, Outward (°)	32.13	-	-

### CIVIC Type R All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	7.5	8	8.5
Right Front Caster (°)	7.5	8	8.5
Left Front Camber (°)	-1.83	-1.33	-0.83
Right Front Camber (°)	-1.83	-1.33	-0.83
Front Toe (°)	-0.17	0	0.17
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-2.25	-1.5	-0.75
Right Rear Camber (°)	-2.25	-1.5	-0.75
Rear Toe (°)	0.08	0.17	0.33
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	32.98	34.98
Left Max Turn, Inward (°)	36.98	32.98	34.98
Right Max Turn, Inward (°)	36.98	28.85	29.85
Left Max Turn, Outward (°)	30.85	28.85	29.85
Right Max Turn, Outward (°)	30.85	-	-