Quick start guide




Download the app from the App Store to your phone, it will help you to setup your clock.







Turn on your clock by holding the button on the right side. You will see the 'Hello' sign once it is turned on. If you see the sign you need to charge the clock. Launch the Glance Clock app and follow the instructions on the screen.





To charge your clock, locate the connector slot at the back of your device. Remove the charging cable from the box and connect to the clock. Insert USB connector to the provided charger and plug in to the wall outlet. You can now try switching on your clock again. Please charge your clock for at least 2 hours. You can continue with the setup process simultaneously.



Power Status



The battery is dead and the clock cannot be turned on. Charge your clock for at least 2 hours.



The battery level is less than 15%. The clock needs to be charged.

·#:[III]

When the changing cable is plugged in the indicator shows that the clock is fully charged.

III)50

When you remove the cable the clock shows you the battery level.

Glance Clock

You can always check the battery level in Glance Clock app.

Hang your clock



To hang your Glance Clock to a wall you will need a screw and dowel that is appropriate for your wall type. Please ask for a 4mm countersunk screw with dowel in your hardware store.




Take the hanger and remove the cap (with the Glance Clock logo). Drill a hole in the wall and place the dowel into the hole. Place the hanger against the hole and screw in the 4mm screw through the hole in the hanger. Place the cap back.




Check that the hanger is firmly attached to the wall. Take the Glance Clock and hang it to the hanger. The Glance Clock should be hanging vertically.




Plug in the cable to the clock, insert the USB plug into the adapter, then plug in the power adapter. USB-type adapter and wall mount plug are shown for the reference. Please use the provided power adapter appropriate for your country.









QUICK START GUID

Features

- ☆ Your favorite apps
- Useful recipes
- (3) Information as a Glance Clock face
- C Do Not Disturb (DND) mode
- 🖄 Silent mode
- Date, time, twelve hourly dots

Technical Support Information

For detailed information how to use Glance Clock, please refer to Glance Clock Manual at glanceclock.com/manual

For support inquiries, please contact support@qlanceclock.com

Certification

FCC AND IC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: reorient or relocate the receiver antenna, increase the separation between the equipment and receiver, connect the equipment into an outlet on a circuit different from that to which the receiver is connected, consult the dealer or an experienced radio/TV technician for help-

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference

What is in the box



Glance Clock - 1 pcs



Hanger cap with logo - 1 pcs Hanger - 1 pcs



Power Adapter - 1 pcs.*

Input: 100-240V 50/60Hz 0.5A max Output: 5V 1.5A

* This picture is given for your reference

You will find a charger with a plug type for your country in the box.



Charging Cable - 1 pcs 3m (10ft) long DC Jack OD 3.5mm ID 1.4mm USB-A

(2) This device must accept any interference received, including interference that may cause undesired operation.

DECLARATION OF CONFORMITY WITH REGARD TO THE EU DIRECTIVE

Glance Tech Pte. Ltd. is authorized to apply the CE (Conformité Européene) Mark on its product, thereby declaring conformity to the essential requirements and other relevant provisions of directive 1999/5/EC and other applicable directives.

Caution! The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

Disposal and Recycling Information

The symbol on the product or its packaging signifies that this product has to be disposed separately from ordinary household wastes at its end of life. Please kindly be aware that it is your responsibility to dispose electronic equipment at recycling centers so as to help conserve natural resources.

Each country in the European Union should have its collection centers for electrical and electronic equipment recycling. For information about your recycling drop off point, please contact your local related electrical and electronic equipment waste management authority or the retailer where you bought the product.

- Do not dispose of your glance product with household waste
- · Disposal of the packaging and your glance product should be done in accordance with local regulations.

 Batteries are not to be disposed of in municipal waste stream and require separate collection:

PLEASE RECYCLE!

Warranty Information

Glance Tech Pte. Ltd. is covered by a 1 year limited warranty that covers defects in workmanship and / or materials for a period of 1 year from original purchase date. This warranty does not apply to any products which have been abused, neglected, modified or used for a purpose other than the one for which they were manufactured. Warranty terms may be revised without notification at the discretion of the manufacturer.

For warranty work contact: 71 Aver Raiah Crescent, #01-23, Singapore

Contact Support: support@olanceclock.com

Online Product Support: glanceclock.com/faq

Glance Clock by Glance Tech Pte. Ltd. Designed in Singapore. Assembled in Malaysia. All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.





FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.