
USB Mode Test DEMO Use Introduction

一、Before using the test DEMO, please install the finger vein drive;


1. Insert the USB port into the PC terminal correctly, double-click the SetupDriver3.msi under the driver folder, and wait for the device to install the driver automatically. The drive installation interface is shown in the figure below.



2、After the drive installation is completed, check the PC device manager if there is a Android ADB or Android Phone device, if the installation is successful.



二、Double-click the FXs.exe application under the Release folder to open Test DEMO, as shown in the figure below



1、Select the device number, and the default device is 0

2、Click [Open device], in the prompt box will show whether the device is opened successfully.

3、modeling:

a、In the ID 3 area, enter the name / ID.

b、In the logo 4 area, click to start the modeling.

c、Take the left index finger as an example, place the left index finger in the image acquisition area, touch the fingertip contact gently, put the finger naturally, do not press the finger, to complete the first image acquisition. Image preview area to view finger vein images.

d、Remove the left index finger, and, according to the prompts, place the left index finger correctly in the image acquisition area again to complete the second image acquisition.

e、Repeat the previous step to complete the third image acquisition, DEMO automatically completes the modeling work, and in the prompt information box, prompt the name / ID for modeling.


4、Certification identification: 1:1 certification identification and 1: N certification identification.

A, 1:1 authentication identification, input the name / ID in 6 area, click [1:1 authentication identification] in 5 area, put the finger in the image acquisition area, touch the fingertip contacts, the device starts authentication identification, give authentication results in the prompt information window, and give the buzzer and LED indicator light.

remarks:

Certification success: green light flashing, buzzer short sound;

Certification failure: red light flashing, buzzer short sound two sound;



B, 1: N authentication and recognition, click the identification 7 area, place the finger in the image acquisition area, fingertip gently touch the fingertip contact, the device starts authentication and identification, give the authentication results in the prompt information window, and give the buzzer and LED indicator prompt.

other:

1、Click the identification 8 area, place the finger in the image acquisition area, and automatically identify 100 times, the prompt information box, and the lower left corner of DEMO.

2、Click the identification 9 area to exit the authentication identification.

3、Click area 10 to exit the test DEMO.

4、Click area 11 to test and configure the red-green indicator and buzzer.

5、System configuration: refers to the system parameters of the recognition izer and must not be modified.