## VK4GHZ Nextion for K3NG Rotator Controller

## 5.0" Nextion Font Table

When adding fonts into this Nextion HMI project, the fonts MUST be imported so they are correctly referenced to their designated font id number.

Import fonts in the following order, and/or use the Editors up/down arrows to move them into the correct slots.




Font id:	Font
0	AA-Calibri-24
1	AA-Calibri-32
2	AA-Calibri-40
3	AA-Calibri-16B
4	AA-Arial-Condensed-24B
5	AA-Calibri-40B
6	AA-Calibri-48
7	AA-Calibri-56B
8	AA-Calibri-80B
9	AA-Calibri-96B
10	AA-Arial-Condensed-48B
11	AA-Digital7Mono-72
12	AA-DigitalMono-80
13	AA-Arial-Condensed-32B
14	AA-Digital7Mono-24B
15	AA-Digital7Mono-32B
16	AA-Digital7Mono-212
17	AA-Calibri-24B

If you choose to use different fonts, try to keep the same font size for each font id, otherwise major reorganisation of the screen components will be required. It's tight for room!

All fonts encoded iso-8859-1 and anti-alaised.

Ensure your HMI display character encoding is also set to iso-8859-1.



iso-8859-1 ▼