# گزارش تمرین چهارم

درس ابزار دقیق

دکتر نیر*ی* 

رضا مومني

810199497

انتقال داده	کاربرد	صحت سنجى ديتا	Max Bitrate	نام پروتكل
دو طرفه است	ارتباط نقطه ای	صحت سنجی دیتا را پشتیبانی نمیکند	115.2kbps	UART
چند مستر و	سنسورها و	صحت سنجی دیتا دارد و دیتای قابل اعتمادی را	5000kbps	I2C
اسليو	EEPROM	تضمین میکند		
	فاصله کم			
MASTER	SCADA	پشتیبانی نمیکند	115.2kbps	Modbus
SLAVE	PLC			
چند مستر و چند	Automotive	CAN includes error-checking	1000kbps	CAN
نود باس	systems	mechanisms (CRC) for robustness		
	(ECUs),			
	industrial			
	automation,			
	and robotics			

## 1. UART (Universal Asynchronous Reception and Transmission):

- **Speed**: UART is full-duplex communication and generally faster than I2C. It can reach speeds of a few Mbps.
- o **Data Validation**: UART does not inherently provide data validation; it relies on higher-level protocols or application-specific mechanisms.
- Data Transfer: Bi-directional asynchronous serial data transmission using two lines (TX and RX).
- o **Precision**: No inherent precision; depends on the application.
- o **Applications**: Commonly used for point-to-point communication (e.g., USB to a computer, sensor modules).

#### 2. I2C (Inter-Integrated Circuit):


- o **Speed**: I2C offers moderate data rates 100 kbps to 5 Mbps.
- o **Data Validation**: I2C performs data validation, ensuring reliable data transfer.
- o **Data Transfer**: Multi-master, multi-slave bus with flow control.
- o **Precision**: Up to 3.4 MHz speed; suitable for precision applications.
- Applications: Used for connecting sensors, EEPROMs, and other peripherals within short distances.

#### 3. CAN (Controller Area Network):


- o **Speed**: CAN Bus data rates vary (low to high), with maximum speeds of 1 Mbps.
- o **Data Validation**: CAN includes error-checking mechanisms (CRC) for robustness.
- **Data Transfer**: Multi-master, multi-node bus for industrial automation and automotive applications.
- o **Precision**: Designed for reliability and fault tolerance.
- Applications: Automotive systems (ECUs), industrial automation, and robotics.

### 4. Modbus:

- Speed: Modbus speed varies based on the implementation (typically slower than UART or I2C).
- Data Validation: Modbus lacks built-in data validation; error checking is application-specific.
- o **Data Transfer**: Simple master-slave protocol (RTU or ASCII).
- o **Precision**: Typically used for control and monitoring, not high precision.
- o **Applications**: SCADA systems, PLCs, and industrial control.



**I2C** circuit



**CAN** circuit

# SIMULATION

Question 1

810199497 % 3 = 0 => MC: STM32F103C6

SID % 9 = 3 => HCLK: 26 MHz | X1 = PA2, X2 = PA9 | Y1 = PB0, Y2 = PB5

I.


بدنه اصلی کد که در while بدنه اصلی کد که در while بدنه اصلی کد که در است:

```
while (1)

/* USER CODE END WHILE */

/* USER CODE END 3 */


/* USER CODE
```




II.

```
while (1)
102
103
104
             /* USER CODE END WHILE */
                led1 = HAL_GPIO_ReadPin(GPIOB, Y1_Pin);
105
106
                          if (led1==0){
107
                                 HAL_GPIO_WritePin(GPIOA, x1_Pin, GPIO_PIN_SET);
HAL_GPIO_WritePin(GPIOA, x2_Pin, GPIO_PIN_RESET);
108
109
110
111
                          if (led2==0){
   HAL_GPIO_WritePin(GPIOA, x2_Pin, GPIO_PIN_SET);
   HAL_GPIO_WritePin(GPIOA, x1_Pin, GPIO_PIN_RESET);
112
113
114
115
         led2=1;
/* USER CODE BEGIN 3 */
/* USER CODE BEGIN 3 */
}
116
117
118
119
```


مزیت اصلی که اینتر اپت نسبت به مستقیم خواندن مقدار دارد این است که با حذف دیلی هایی ناشی از توابعی مثل hal\_gpio\_readpin میتوان به سرعت بیشتری دست پیدا کرد. همچنین اینتر اپت با کلاک اصلی خود میکرو کار میکنه و نیازی به دیلی خارجی نداره.






```
SystemClock_Config();
83
     MX_GPIO_Init();
84
85
       LCD16X2_Init(MyLCD);
86
        LCD16X2_Clear(MyLCD);
87
88
        LCD16X2_Set_Cursor(MyLCD, 1, 1);
        LCD16X2_Write_String(MyLCD, "Reza Momeni");
89
        LCD16X2_Set_Cursor(MyLCD, 2, 1);
90
        LCD16X2_Write_String(MyLCD, "810199497");
91
92
      /* USER CODE BEGIN SysInit */
```

II.



از آنجایی که مستقیما نمیتوان اعداد اعشاری را نمایش داد پس با کد زیر میتوان به خروجی بالا دست پیدا کرد. یعنی ما اجزای عدد اعشاریمان را به صحیح تبدیل کنیم و از آن استفاده کنیم.

```
maiin = f;
92
      dec = (f*100);
93
        dec = dec%100;
94
95
96
97
98
        LCD16X2_Init(MyLCD);
99
        LCD16X2_Clear(MyLCD);
100
101
        LCD16X2_Set_Cursor(MyLCD, 2, 1);
102
        sprintf(fl, "%d", maiin);
103
        LCD16X2_Write_String(MyLCD, fl);
104
        LCD16X2_Write_Char(MyLCD, dot);
105
        sprintf(deci, "%d", dec);
106
        LCD16X2_Write_String(MyLCD, deci);
107
        sprintf(in, "%d", i);
108
        LCD16X2_Set_Cursor(MyLCD, 1, 1);
109
        LCD16X2 Write String(MyLCD, in);
110
      /* USER CODE BEGIN SysInit */
111
```



بعد از مدتی همانطور که مشاهده می شود عدد صحیح 0 شده و عدد اعشاری بدون تغییر باقی میماند. این به این دلیل است که تعداد بیت ظرفیت این متغیرها پر شده و overflow رخ داده است. برای داشتن متغیری با ظرفیت بیشتر میبایست از تایپ های دیگری از متغیرها مثل ount16 و long و double استفاده کنیم که ظرفیت بیشتری دارند.

```
while (1)
105
106
         /* USER CODE END WHILE */
107
           maiin = f;
108
             dec = (f*100);
109
               dec = dec%100;
110
111
112
113
114
                 LCD16X2_Init(MyLCD);
115
               LCD16X2 Clear(MyLCD);
116
117
               LCD16X2_Set_Cursor(MyLCD, 2, 1);
118
               sprintf(fl, "%d", maiin);
119
120
               LCD16X2_Write_String(MyLCD, fl);
               LCD16X2_Write_Char(MyLCD, dot);
121
               sprintf(deci, "%d", dec);
122
               LCD16X2_Write_String(MyLCD, deci);
123
               sprintf(in, "%d", i);
124
               LCD16X2_Set_Cursor(MyLCD, 1, 1);
125
126
               LCD16X2_Write_String(MyLCD, in);
           LCD16X2_SR(MyLCD);
127
           f = f*2;
128
           i = i*2;
129
           HAL_Delay(1000);
130
           LCD16X2_SL(MyLCD);
131
```