




Transition not enabled

The transitions are not enabled, because the steps 9 or 10 resp. are not activ.
The corresponding transition conditions may be true or false.