SPRINT-2

Date	3 November 2022
TEAM ID	PNT2022TMID26938
Project Name	IoT Based smart crop Protection system for agriculture
Maximum mark	20 marks

STEP1: Download and Install NODE JS.

macOS Installer (.pkg)

macOS Binary (.tar.gz) Linux Binaries (x64)



64-bit / ARM64

64-bit

ARM64

STEP2: Setup node.js and configure command prompt for error check.open node-red from the generated link.

```
A Nov 18:48:85 - [info] Node-RED version: v3.0.2

4 Nov 18:48:95 - [info] Node-RED version: v18.12.0

4 Nov 18:48:95 - [info] Node.js version: v18.12.0

4 Nov 18:48:95 - [info] Nindows_NT 10.0.19944 x64 LE

4 Nov 18:48:26 - [info] Settings file : C:\Users\ELCOT\.node-red\settings.js

4 Nov 18:48:45 - [info] Settings file : C:\Users\ELCOT\.node-red

4 Nov 18:48:45 - [info] Settings file : C:\Users\ELCOT\.node-red

4 Nov 18:48:45 - [info] User directory : Users\ELCOT\.node-red

4 Nov 18:48:45 - [info] Destrings file : Users\ELCOT\.node-red

4 Nov 18:48:45 - [info] Destrings file : Users\ELCOT\.node-red\flows.json

4 Nov 18:48:45 - [info] Creating new flow file

4 Nov 18:48:45 - [info] Creating new flow file

Your flow credentials file is encrypted using a system-generated key.

If the system-generated key is lost for any reason, your credentials


file will not be recoverable, you will have to delete it and re-enter
your credentials.

You should set your own key using the 'credentialSecret' option in
your settings file. Node-RED will then re-encrypt your credentials

file using your chosen key the next time you deploy a change.

4 Nov 18:48:45 - [warn] Encrypted credentials not found
4 Nov 18:48:45 - [info] Starting flows
4 Nov 18:48:46 - [info] Started flows
4 Nov 18:48:46 - [info] Started flows
```

STEP3: Connect IBM IOT in and Debug 1 and Deploy.



STEP4: Edit gauge node (Here the gauge nodes are named as Temperature, Humidity and Soil moisture).

