
MAKE OUTPUT IN NODE-RED

Sprint_10


Team ID: PNT2022TMID29941


IBM ID: IBM-Project-31889-1660205917

Make Sure that Device Simulator is running




In the recent events Your output well excuted;





sprint004 Based on the devices id and types are noted to connect node red

Add few funtion box in flow space:




Device ID


mainproject

Device Type

connect the both function in one line



In ibm iot menu add some key



Device ID; mainproject Device Type; sprint004 API-KEY;

Click DEPLOY

