## Assignment-II

Topic: PYTHON CODE TO GET TEMPERATURE AND HUMIDITY VALUE

Name: DHINESH.M

Register Number: 920819106015

E-Mail ID: <a href="mailto:dhineshkumar93262@gmail.com">dhineshkumar93262@gmail.com</a>

Code:

# import standard python modules.

import time

# import adafruit dht library.

import Adafruit\_DHT

# import Adafruit IO REST client.

from Adafruit\_IO import Client, Feed

# Delay in-between sensor readings, in seconds.

DHT\_READ\_TIMEOUT = 5

# Pin connected to DHT22 data pin

DHT\_DATA\_PIN = 26

# Set to your Adafruit IO key.

# Remember, your key is a secret,

# so make sure not to publish it when you publish this code!

ADAFRUIT\_IO\_KEY = 'YOUR\_AIO\_KEY'

```
# Set to your Adafruit IO username.
# (go to https://accounts.adafruit.com to find your username).
ADAFRUIT_IO_USERNAME = 'YOUR_AIO_USERNAME'
# Create an instance of the REST client.
aio = Client(ADAFRUIT_IO_USERNAME, ADAFRUIT_IO_KEY)
# Set up Adafruit IO Feeds.
temperature_feed = aio.feeds('temperature')
humidity_feed = aio.feeds('humidity')
# Set up DHT22 Sensor.
dht22_sensor = Adafruit_DHT.DHT22
while True:
  humidity, temperature = Adafruit_DHT.read_retry(dht22_sensor, DHT_DATA_PIN)
  if humidity is not None and temperature is not None:
    print('Temp={0:0.1f}*C Humidity={1:0.1f}%'.format(temperature, humidity))
    # Send humidity and temperature feeds to Adafruit IO
    temperature = '%.2f'%(temperature)
    humidity = '%.2f'%(humidity)
    aio.send(temperature_feed.key, str(temperature))
    aio.send(humidity_feed.key, str(humidity))
  else:
    print('Failed to get DHT22 Reading, trying again in ', DHT_READ_TIMEOUT, 'seconds')
  # Timeout to avoid flooding Adafruit IO
  time.sleep(DHT_READ_TIMEOUT)
```