

## SIMATIC HMI FACTORY RESETTING

DOC No

:ICP\_SIMATIC\_HMI\_RESET

Revision

: 0.0

**Last Modified** : 30-10-2023

# SIMATIC HMI FACTORY RESETTING (TP900 COMFORT)

#### **REVISION HISTORY**

Initial Release for Review	00	30-10-2023	PK		
REVISION DETAILS	REVISION	REV. DATE	PREP. BY	CHECKED	APPROVED

#### COPY RIGHT

All rights reserved by ICpro Solutions Pvt. Ltd. Reproduction or issue is not permitted without the written permission of ICpro Solutions Pvt. Ltd.



### SIMATIC HMI FACTORY RESETTING

DOC No :ICP\_SIMATIC\_HMI\_RESET

Revision : 0.0

**Last Modified** : 30-10-2023

#### **Factory Retting of HMI:**

1. In TP900 Comfort HMI have protected with security options with password.

- 2. Once the password is enabled then only, we can able to configurations perform in HMI.
- **3.** Here the password was forgotten, so can't able to configurations in HMI, It went to "Secure Mode"
- **4.** So, we need to factory resetting for this HMI, In the time of resetting is loading but no other result shown.



Note: HMI version (16.1) in time of security configuration problem. HMI Current version (15.1) for solving the factory resetting.





# SIMATIC HMI FACTORY RESETTING


DOC No :ICP\_SIMATIC\_HMI\_RESET

Revision : 0.0


**Last Modified** : 30-10-2023

## **Steps to be followed for HMI Factory Resetting:**

1. Open the TIA Portal and select the respective HMI device



2. Selecting the Device configuration and assign the existing IP address of the HMI






## SIMATIC HMI FACTORY RESETTING

DOC No :ICP\_SIMATIC\_HMI\_RESET


Revision : 0.0

Last Modified : 30-10-2023

3. Drag and drop some elements from the tools box and save the project



4. Download the new project to the HMI



**5.** Give the start search and the respective HMI's IP Address and the device shown in the Target device section.



#### SIMATIC HMI FACTORY RESETTING


DOC No :ICP\_SIMATIC\_HMI\_RESET

Revision : 0.0

Last Modified : 30-10-2023

**6.** Current firmware version of the HMI is V 16.1, our current HMI backup version is 15.1, so it asking for the **HMI to Downgrade the Firmware version.** 

- 7. "Click OK" for the Downgrade the Version of HMI.
- **8.** In the time downgrading our present development version 15.1 download to the HMI and the "same time HMI will be functioning Factory resetting" automatically.
- 9. Once the Backup is download and verify the all the security options were disabled
- 10. And check the all the HMI configurations working without any password setting,
- **11.** Once resetting completed, then download the Existing Developing backup from existing version is TIA Portal 16.1 and it asking for the **HMI to Upgrade the Firmware version.**
- 12. "Click OK" for the Upgrade the Version of HMI.
- **13.** Once the Backup is download and verify the all the security options were disabled and check the all the HMI configurations working without any password setting.



<u>Note:</u> Check the power connection/supply of the HMI; there should be no Power Interrupt/Failure in the HMI during firmware upgrade or downgrade. Using a UPS power supply for firmware upgrade or downgrade is safer.