
# Modelo Entidad-Relación

#### **FACILITIES**

ID\_FACILITIES (Primary Key)
GUID\_FACILITIES
NAME\_FACILITIES
DESCRIPTION\_FACILITIES
CATEGORY\_FACILITIES
ADDRESS\_FACILITIES




## **FLOORS**

(I,N)

(I,N)

ID\_FLOORS (Primary Key)
GUID\_FLOORS
NAME\_FLOORS
DESCRIPTION\_FLOORS
HEIGHT\_FLOORS
ID\_FACILITIES (Foreign Key)

(I,I)



## **SPACES**

ID\_SPACES (Primary Key)
GUID\_SPACES
NAME\_SPACES
DESCRIPTION\_SPACES
CATEGORY\_SPACES
USABLEHEIGHT
AREA
ID\_FLOORS (Foreign Key)

## COMPONENTS

ID\_COMPONENTS (Primary Key)

GUID\_COMPONENTS

NAME\_COMPONENTS


DESCRIPTION\_COMPONENTS

SERIALNUMBER

INSTALLATION

ID\_SPACES (Foreign Key)

ID\_TYPES (Foreign Key)



#### **TYPES**

ID\_TYPES (Primary Key)
GUID\_TYPES
NAME\_TYPES
DESCRIPTION\_TYPES
MODELNUMBER
COLOR
WARRANTYYEARS