Serge Modular 73-75 Panels

NYU Ability Project

Tactile Synths

NYU Ability Project / IDM

Created by:

Stefanie Koseff, Faculty Lead

Madeline Mau

Moira Zhang

Ciarra Black

Izabella Rodrigues

Jason Wallach

Lauren Race

R. Luke DuBois, Faculty Advisor

⠏⠁⠝⠑⠇ ⠛⠥⠊⠙⠑ panel guide

VOICE	OSC	OSC	TWS	VCF	VCA	VCA	RING	ENV	ADP
CONTROL	NOI	POS	NEG	COM	PRC	SSG			
HOMEBUILT #1	OSC	TWS	P&T	COM	PRC	VCA	RING	RVB	PRE
HOMEBUILT #2	POS	NEG	ENV	ENV	ENV	ADP			
PRESET	SEQ	PRG	TBS						

table of contents

KEY

symbol key


ac input


ac output


dc input


dc output


pulse input


pulse output


misc input


misc output


basic knob


offset knob


scale knob


button


trs input


trs output

OSC

oscillator

sine ac

sine dc

saw dc

fm

fm ×

sync

ws ×

waveshape

saw ac

fm

fm ×

frequency

TWS

triple waveshaper

a vc1	a vc2	a out
a ×	a in	a out
b vc1	b vc2	b out
b ×	b in	b out
c vc1	c vc2	c out
c ×	c in	c out

P&T

peak & trough

peak out	trough out
peak out	trough out
peak in	trough in
peak in	trough in
peak in	trough in
peak in	trough in

COM

triple comparator

a in 1	a out
a thresh	a in 2
b in 1	b out
b thresh	b in 2
c in 1	c out
c thresh	c in 2

PRC

dual processor

a in 1	a 1 ×	a out
a in 2	a 2 ×	a out
a in 3	a 3 ×	a offset
b in 1	b 1 ×	b out
b in 2	b 2 ×	b out
b in 3	b 3 ×	b offset

VCA

gate

out

ac

dc

lin

log

gain

⠗⠊⠝⠛ RING

⠗⠬ ⠍⠕⠙⠥⠇⠁⠞⠕⠗ ring modulator

⠳
out

⠽
y

⠧⠉ ⠽
vc y

⠭
x

⠧⠉ ⠭
vc x

⠭ ⠤ ⠭⠽
x - xy

RVB

reverberator

out

out

mix

wet

wet

in

PRE

preamplifier

input

gain

out

out

POS

positive slew

a vc

a vc ×

a offset

b vc

b vc ×

b offset

a in

a start

a sustain

b in

b start

b sustain

a out

a high

a end

b out

b high

b end

NEG

negative slew

a vc	a in	a out
a vc ×	a end	a out
a offset	a end	
b vc	b in	b out
b vc ×	b end	b out
b offset	b end	

⠑⠝⠧ ENV

envelope generator

end	out	window
start in	out	window offset
cycle	hold	window vc
		duration vc
rise	fall	duration ×

ADP

adapter

a out

a in

b out

b in

c out

c in

NOI

noise source

white

pink

s/h ac

stepped ac

manual

white

pink

s/h dc

stepped dc

trigger

VCF

filter

- high
- band
- low
- Q
- freq vc
- freq vc ×

- high
- band
- low
- input
- gain
- frequency

SSG

smooth & stepped generator

smooth vc

smooth vc ×

smooth vc offset

stepped vc

stepped vc ×

stepped vc offset

smooth out

smooth cycle

smooth hold

stepped sample

stepped cycle

stepped out

smooth in

coupler

coupler

stepped in

SEQ

sequencer

5 out	5 out	6 out	6 out
4 out	4 out	7 out	7 out
3 out	3 out	8 out	8 out
2 out	2 out	9 out	9 out
1 out	1 out	10 out	10 out
clock	hold	reset	step

PRG (1/3)

programmer

1 out	2 out	3 out	4 out
1 a	2 a	3 a	4 a
1 b	2 b	3 b	4 b
1 c	2 c	3 c	4 c
1 in	2 in	3 in	4 in
select	select	select	select

PRG (2/3)

programmer

5 out	6 out	7 out	8 out
5 a	6 a	7 a	8 a
5 b	6 b	7 b	8 b
5 c	6 c	7 c	8 c
5 in	6 in	7 in	8 in
select	select	select	select

PRG (3/3)
programmer

all out	all out
cv a out	cv a out
cv b out	cv b out
cv c out	cv c out

TBS

bi-directional router

a1	select
a	a2
b1	select
b	b2
c1	select
c	c2