Precitec Macro Documentation

04 End of Seam Marker after xx images

Changelog

Date	Version	Autor	Tested on	Description
2022-06-22	A	Wre	5.16.16	New documentation

Description



Sends an End of Seam Marker after xx images. Needs image input.

I1: Image

- **Macro structure**



Sends an End of Seam Marker after xx images. Needs image input. Image number starts to count at 0. Stop Image number can be chosen inside the macro.

- **Parameter**

NAME	**VALUE**	Description	UserLevel
00 Image number xx → Number	**0**	Image number on which the seam shall end (first image number = 0)	Operator

© Precitec