Precitec Macro Documentation

01 ROI from Seam Details

Changelog

Date	Version	Autor	Tested on	Description
2022-04-12	A	Wre	5.16.0	New documentation
2022-06-09	B	Wre	5.16.16	UserLevels Bug fixed

Description



Generates ROI according to the selection on the SeamDetails page

I1: Image

O1: ROI

O2: ROI x

O3: ROI y

O4: ROI w

O5: ROI h

- **Macro structure**



Needs an Input Image: e.g. Image Source

Outputs the ROI, which is an image cropped down to the size of the ROI.

Outputs the x- and y-Position as well as the width and height of the ROI in pixel.

- **Parameter**

NAME	**VALUE**	Description	UserLevel
00 Dynamic ROI → Green channel	**255**	Green color of ROI Box	Operator
00 Dynamic ROI → Red channel	**0**	Red color of ROI Box	Operator
00 Dynamic ROI → Blue channel	**0**	Blue color of ROI Box	Operator
00 Dynamic ROI → Verbosity	**Low**	Visibility of ROI Box	Operator
00 Dynamic ROI → Alpha Channel	**255**	Transparency of ROI Box	Operator

© Precitec