


5 - S91 CALC Ablation width


Description

Measure left and right ablation width.

Icon



Parameters





Parameter	Comment
Filter length	Number of camera images to average the measured ablation width on the left side of the seam. [Images].



Parameter	Comment
Filter length	Number of camera images to average the measured ablation width on the right side of the seam. [Images].

Measured values for plotter

589	0 xxx	Width ablation left
590	0 xxx	Width ablation right

Subgraphs interface

IN bridges OUT bridges

 image	Img	 ☑ value	Ablation width left
			Ablation width right
	Seam pos left filtered		
	Seam pos right filtered		
	ROI grey valid		
	Ablation out X left		
	Ablation out X right		



■ Graph block diagram

