Case 4		
Use Case Step	**Information Transfer**	**Transaction level functions**
1. Patient admitted to hospital		ADT Placer sends ADT^A01 to admit patient. The CIS receives this but the device does not receive this.
2. Nurse initiates/uses bedside flowsheet on patient		
3. Nurse positions bedside device		
4. Nurse barcode-scans bedside device	Nurse barcode-scans monitor (from CIS, using same scanner as used for meds administration; monitor ID now known to CIS)	
5. Nurse starts bedside device		
6. Device data flows to flowsheet	The device does not use the ADT Placer assigned patient id within the message. The CIS system has made the association between the device and the patient.	Device or gateway sends ORU^R01
7. Nurse validates data on the flowsheet to be included in patient permanent record.		