U4
74HC245
U1
74HC245
U3
74HC245
X1
DIN41612_02x32_AC
J4
CONN_01X01
JP3
Jumper_NO_Small
U7
74HC273
Page Latch
Switches not normally fitted,
J7 allows the pads to be shorted
out for initial programming.
J7
Conn_01x04_Socket
RN5
4K7
F_Enable
SW1
SW_DIP_x02
U2
SST39SF010
39SF010 (128K) fitted as standard.
Both switches on allow the full
128K to be used, or treat as
4 x 32K sections for alternative
filing systems.
39SF010 only goes up to A16.
RN1
RN2
RN3
RN4
4K7
CH376 Header (USB)
J2
Conn_02x08_Odd_Even
RN6
680R
J3
J6
J5
CONN_02X20
CONN_02X22
J1
CONN_01X02
LED
U5A
74HC139
U5B
74HC139
U6A
74HC139
U6B
74HC139
Flash
Disable
JP1
Jumper_NO_Small
Short to disable the flash
if the contents prevents
the machine from starting.
No need for jumper pins
just poke a wire in the
holes if needed.
U5C
74HC139
U6C
74HC139
C1
47uF 16V
100n
VCC
GND

Sheet: /	
File: ide_podule-16bit.kicad_sch	
Title:	
Size: A3	Date: zondag 28 september 2014
KiCad E.D.A. 8.0.8	Id: 1/1
	Rev: