Prentice Hall



ORG; SEVENTEEN

SERIAL PORT **PROGRAMMING** WITH ASSEMBLY AND C#

The x86 PC

assembly language, design, and interfacing

fifth edition

MUHAMMAD ALI MAZIDI JANICE GILLISPIE MAZIDI **DANNY CAUSEY**


OBJECTIVES this chapter enables the student to:

- List the advantages of serial communication over parallel communication.
- Explain the difference between synchronous and asynchronous communication.
- Define the terms simplex, half duplex, and full duplex and diagram their implementation in serial communication.
- Describe how start and stop bits frame data for serial communication.

this chapter enables the student to:

- Contrast and compare the measures baud rate and bps. (bits per second)
- Describe the RS232 standard.
- Contrast and compare DTE (data terminal) versus DCE (data communication) equipment.
- Describe the purpose of handshaking signals such as DTR, RTS, and CTS.
- Code Assembly language instructions to perform serial communication using BIOS INT 14H.
- Describe the function of UART and USART chips.

- A microprocessor communicates with the outside world by providing data in byte-sized chunks.
 - Devices such as printers, grab data from the 8-bit data bus, and present to the 8-bit printer data bus.
 - An 8-Bit data path is expensive; signals can be diminished or distorted by cable length.





The x86 PC

Assembly Language, Design, and Interfacing

By Muhammad Ali Mazidi, Janice Gillespie Mazidi and Danny Causey

- As serial communication uses a single data line, it is possible for two computers located in two different cities to communicate over the telephone.
 - It is also much cheaper.
- Outgoing data must be grabbed from the 8-bit data bus of the microprocessor, and converted to serial bits, using a parallel-in-serial-out shift register.
 - The receiving end has a serial-in-parallel-out shift register.
 - To receive serial data, pack it into a byte, and present it to the system at the receiving end.

- Data transferred on the telephone line must be converted from 0s and 1s to audio tones.
 - Sinosoidal-shaped signals.
- This conversion is performed by a modem.
 - Short for "modulator/demodulator."


- Serial data communication uses two methods:
 - Synchronous transfers a block of data (characters) at a time.
 - Asynchronous transfers a single byte at a time.
- Special IC chips are made by many manufacturers for serial data communications, commonly referred
 - UART (universal asynchronous receiver-transmitter
 - USART (universal synchronous-asynchronous receivertransmitter).
 - The x86 COM port uses the UART.

17.1: BASICS OF SERIAL COMMUNICATION half- and full-duplex transmission

- During simplex transmissions, such as with printers, the computer only sends data.
- A duplex transmission is one in which the data can be transmitted and received.

17.1: BASICS OF SERIAL COMMUNICATION half- and full-duplex transmission

- Duplex transmissions can be half- or full-duplex.
 - Data transmitted one way at a time is called half duplex.
 - Data going both ways at the same time is full duplex.






17.1: BASICS OF SERIAL COMMUNICATION protocol/usage

- Incoming data at the receiving end of the data line in a serial data transfer is all 0s and 1s.
 - To make sense of the data, sender and receiver agree on a set of rules, a protocol...
 - How the data is packed.
 - How many bits constitute a character.
 - When the data begins and ends.
- Asynchronous serial data communication is widely used for character-oriented transmissions.
 - Block-oriented data transfers use synchronous transfer.

17.1: BASICS OF SERIAL COMMUNICATION data framing - start and stop bits

 In asynchronous communications, the data, such as ASCII characters, are packed between a start bit and a stop bit, a process called framing.

ASCII character "A", binary 0100 0001, framed between the start bit and 2 stop bits.



- The start bit is always one bit and always a 0. (low)
- The **stop** bit can be one or two bits, and is 1 (*high*).

Fig. 17-1 Framing ASCII "A" (41H)



17.1: BASICS OF SERIAL COMMUNICATION data framing - start and stop bits

- Asynchronous peripheral chips and modems can be programmed for data 5, 6, 7, or 8 bits wide.
 - In addition to the number of stop bits, 1 or 2.
- When there is no transfer, the signal is 1 (high).
 - Referred to as mark.
 - The 0 (low) is referred to as **space**.




Fig. 17-1 Framing ASCII "A" (41H)



17.1: BASICS OF SERIAL COMMUNICATION data framing - start and stop bits

- Transmission begins with a start bit, followed by D0, the LSB, then the rest of the bits until the MSB (D7)
 - Last, 2 stop bits indicating the end of the character "A".
- Asynchronous peripheral chips and modems can be programmed for data 5, 6, 7, or 8 bits wide.
 - In addition to the number of stop bits, 1 or 2.
- In some older systems, due to slowness of receiving mechanical devices, 2 stop bits were used to give the device time to organize before the next byte.
 - In modern PCs the use of 1 stop bit is common.

The x86 PC

Assembly Language, Design, and Interfacing

By Muhammad Ali Mazidi, Janice Gillespie Mazidi and Danny Causey

17.1: BASICS OF SERIAL COMMUNICATION parity bit

- In some systems, for data integrity, the parity bit of the character byte is included in the data frame.
 - If a system requires it, the parity bit is transmitted after the MSB, and is followed by the stop bit.
 - An odd-parity bit the number of data bits, including the parity bit, has an odd number of 1s.
 - In an even-parity bit, the total number of bits, including the parity bit, is even.
- UART chips allow programming of the parity bit.
 - For odd-, even-, and no-parity options.

17.1: BASICS OF SERIAL COMMUNICATION data transfer rate

Example 17-1

Calculate the total number of bits used in transferring 50 pages, each with 80×25 characters. Assume 8 bits per character and 1 stop bit.

Solution:

For each character a total of 10 bits is used, 8 bits for the character, 1 stop bit, and 1 start bit. Therefore, the total number of bits is $80 \times 25 \times 10 = 20,000$ bits per page. For 50 pages, 1,000,000 bits will be transferred.

The rate of data transfer in serial data communication is stated in bps (bits per second); also baud rate. Baud and bps rates are *not* necessarily equal.

The x86 PC

Assembly Language, Design, and Interfacing

By Muhammad Ali Mazidi, Janice Gillespie Mazidi and Danny Causey

17.1: BASICS OF SERIAL COMMUNICATION data transfer rate

Example 17-2

Calculate the time it takes to transfer the entire 50 pages of data in Example 17-1 using a baud rate of:

(a) 9600 (b) 57,600

Solution:

- (a) 1,000,000 / 9600 = 104 seconds
- (b) 1,000,000 / 57,600 = 17 seconds

Baud rate is modem terminology, defined as number of signal changes per second. As far as the conductor wire is concerned, baud rate and bps are the same

17.1: BASICS OF SERIAL COMMUNICATION data transfer rate

Example 17-3

Calculate the time it takes to download a movie of 2 gigabytes using a telephone line. Assume 8 bits, 1 stop bit, no parity, and 57,600 baud rate.

Solution:

 $2 \times 1,000,000,000 \times 10$ / 57,600 = 347,222 seconds = 4 days

Data transfer rate depends on communication ports incorporated into the system, with today's x86 transferring data at rates as high as 115,200 bps.

In asynchronous serial data communication, baud rate is generally limited to less than 100,000 bps using a telephone line & modem.

- For compatibility in data communication equipment, an interfacing standard called RS232 was set by the Electronics Industries Association (EIA) in 1960.
 - Today, the most widely used serial I/O interface standard.
- RS232 input/output voltage is not TTL compatible:
 - Bit 1 is -3 to -25 V; Bit 0 +3 to +25 V.
 - +3 to -3 is undefined.


Assembly Language, Design, and Interfacing

By Muhammad Ali Mazidi, Janice Gillespie Mazidi and Danny Causey

- To connect RS232 to a TTL-level chip requires voltage converters to convert the TTL logic levels to the RS232 voltage level, and vice versa.
 - MAX232/233 IC chips commonly called line drivers.




 The MAX232 has two sets of line drivers for transferring and receiving data




 The MAX232 T1 line driver has a designation of T1in & T1out on pin numbers 11 & 14, respectively.

USART




T1in pin is the TTL side, connected to TxD of the USART.



T1out is connected to RxD of the RS232 DB connector.

Fig. 17-4 Inside MAX232 and its connection to the USART

 The R1 line driver has a designation of R1in and R1out on pin numbers 13 and 12, respectively.







 MAX232 requires four capacitors ranging from 1 to 22 mF—some designers use the MAX233




Fig. 17-5 Inside MAX233 and its connection to the USART



17.1: BASICS OF SERIAL COMMUNICATION RS232 pins

Pins and their labels for the RS232 cable, which is commonly referred to as the DB-9 connector.




Fig. 17-6 DB9 9-Pin Connector

Table 17-1: IBM PC DB-9 Signals	
Pin	Description
1	Data carrier detect (DCD)
2	Received data (RxD)
3	Transmitted data (TxD)
4	Data terminal ready (DTR)
<u>(3)</u>	Signal ground (GND)
6	Data set ready (DSR)
7	Request to send (RTS)
8	Clear to send (CTS)
9	Ring indicator (RI)

17.1: BASICS OF SERIAL COMMUNICATION data communication classification

- **DTE** (data terminal equipment) refers to terminals and computers that send and receive data.
- **DCE** (data communication equipment) refers to communication equipment, such as modems, responsible for transferring the data.

17.1: BASICS OF SERIAL COMMUNICATION data communication classification

- The simplest connection between two PCs (DTE & DTE) requires pins TxD, RxD, and ground, also referred to as SG (signal ground).
 - Connection between two DTE devices, such as two PCs, requires pins 2 and 3 to be interchanged

RS232 signal definitions are from the point of view of DTE.




Fig.17-7 Null Modem Connection for Data Lines

17.1: BASICS OF SERIAL COMMUNICATION examining the RS232 handshaking signals

- To ensure fast & reliable data transmission between two devices, the data transfer must be coordinated.
 - Some RS232 pins are used for handshaking signals.
- DTR (data terminal ready) when a terminal or PC COM port is turned on, after self-test, it sends signal DTR to indicate it is ready for communication.
 - An output from DTE (COM port); an input to the modem.
- DSR (data set ready) when a DCE (modem) is turned on and has gone through self-test, it asserts DSR to indicate that it is ready to communicate.
 - An active-low signal.



17.1: BASICS OF SERIAL COMMUNICATION examining the RS232 handshaking signals

- RTS (request to send) when the DTE has a byte to transmit, it asserts RTS to signal the modem that it has a byte of data to transmit.
 - An active-low output from DTE; an input to the modem.
- CTS (clear to send) when the modem has room for storing the data it is to receive, it sends signal CTS to DTE (PC) to indicate it can receive the data.
- **CD** (carrier detect, or DCD, data carrier detect) the modem asserts signal CDC to inform DTE (PC) that a valid carrier has been detected and that contact between it and the other modem is established.

17.1: BASICS OF SERIAL COMMUNICATION examining the RS232 handshaking signals


- **RI** (ring indicator) an output from modem (DCE) and input to a PC (DTE), that indicates that the telephone is ringing.
 - ON and OFF in synchronization with the ringing sound.

17.1: BASICS OF SERIAL COMMUNICATION examining the RS232 handshaking signals

- RTS and CTS actually control the flow of data.
 - When the PC wants to send data it asserts RTS
 - If the modem is ready to accept the data, it sends CTS.

RTS and CTS are also referred to as *hardware* flow control signals.

Fig.17-8
Null Modem Connection with Control Signals



17.2: PROGRAMMING x86 PC COM PORTS IBM PC COM ports

- In the x86 PC, as many as four COM ports can be installed, numbered 1, 2, 3, and 4.
 - BIOS numbers them as 0, 1, 2, and 3.
- The PC POST (power-on self-test) tests the USART chip for each of the four COM ports.
 - If they are installed, their I/O port addresses are written to memory locations 0040:0000–0040:0007.

17.2: PROGRAMMING x86 PC COM PORTS using HyperTerminal on x86 PC

•	HyperTerminal is a widely used utility
	that comes with Windows 2000/XP,
	for communication with the x86 PC
	via the serial COM port.

Table 17-2: Some


It is not dynamic, so it cannot be

incorporated into programs

17.2: PROGRAMMING x86 PC COM PORTS programming COM ports using BIOS INT 14H

- Serial communication ports of the x86 PC can be accessed using the BIOS-based INT 14H.
 - Various options of INT 14H are chosen with the AH registers.

See the entire list of BIOS INT14 functions in Fig. 17-9 on pages 456 - 457.





17.2: PROGRAMMING x86 PC COM PORTS programming COM ports using BIOS INT 14H

- Using BIOS INT 14H we can send and receive characters with another PC via a COM port:
 - 1. To send a character...
 - INT 14H, AH = 1, AL = character.
 - 2. To receive a character...
 - INT 14H, AH = 3 (to get COM port status in register AH)
 - 3. To read the received character...
 - INT 14H, AH = 2 (AL holds the character upon return)

The x86 PC

Assembly Language, Design, and Interfacing

By Muhammad Ali Mazidi, Janice Gillespie Mazidi and Danny Causey

17.2: PROGRAMMING x86 PC COM PORTS programming x86 COM port using C# 2005

- To program the COM port we can use System.IO.Ports namespace in C# 2005.
 - Shown in Programs 17-2 and 17-3 on page 459.
 - Program 17-2 writes data to the COM port.
 - Program 17-3 reads data from the COM port.

The x86 PC

Assembly Language, Design, and Interfacing

© 2010, 2003, 2000, 1998 Pearson Higher Education, Inc.


Pearson Prentice Hall - Upper Saddle River, NJ 07458

Prentice Hall

Hex Bin

00010001

ENDS; SEVENTEEN



The x86 PC

assembly language, design, and interfacing

fifth edition

MUHAMMAD ALI MAZIDI JANICE GILLISPIE MAZIDI **DANNY CAUSEY**