The x86 PC

fifth edition

Prentice Hall

Dec Hex Bin 24 18 00011000

ORG; TWENTY-FOUR



THE EVOLUTION OF x86: FROM 32-BIT

The x86 PC

assembly language, design, and interfacing

fifth edition

TO 64-BIT

MUHAMMAD ALI MAZIDI JANICE GILLISPIE MAZIDI DANNY CAUSEY

OBJECTIVES this chapter enables the student to:

- Compare and contrast the variations of Pentium® processors.
- Compare and contrast the variations of x86 32-bit architecture.
- Describe the enhancements of 32-bit architecture in x86 processors.
- Describe the role of L1–L3 caches in x86 processors.
- Describe the role of multicore and multithreading features of x86.
- Describe 64-bit architecture of x86.

The x86 PC

Assembly Language, Design, and Interfacing

© 2010, 2003, 2000, 1998 Pearson Higher Education, Inc.

Pearson Prentice Hall - Upper Saddle River, NJ 07458

24.1: x86 PENTIUM® EVOLUTION Pentium® II to Pentium® IV: an overview


- x86 microprocessor architecture has gone through major changes since the introduction of the first Pentium® processor in 1993.
 - To increase processing power Intel added enhancements to each successive generation of Pentium® II, III, and IV.
 - Most involved internal architecture and did not change the 32-bit register size of the original 386.

The x86 PC

24.1: x86 PENTIUM® EVOLUTION level 1 and level 2 caches

- Pentium® Pro had 8K of cache for code (instruction)
 & 8K for data, feeding code & data to the fetch unit.
 - Called level 1 (L1) cache, it is on the same die as the CPU & works at the same clock speed.






L1 cache feeds code & data to the fetch/execution units and is part of the inner working of the CPU

Fig. 24-1 L1, L2 and L3 Cache

24.1: x86 PENTIUM® EVOLUTION level 1 and level 2 caches

- In Pentium[®] II, level 2 (L2) cache was introduced.
 - L1 cache was increased to 16K each for code & data.
 - 256K bytes of L2 cache was added.




L 2 cache is outside the CPU die, but still on the same package as the CPU itself.

Fig. 24-1 L1, L2 and L3 Cache

24.1: x86 PENTIUM® EVOLUTION level 1 and level 2 caches

- When a Pentium[®] with L2 cache brings in code & data from external DRAM it places them in L2 cache.
- The memory management unit of the CPU brings in the information from L2 cache, separating code & data, placing each in data or code L1 caches. (Harvard architecture)





24.1: x86 PENTIUM® EVOLUTION level 1 and level 2 caches

- L1 code & data caches are separate, as opposed to L2 cache, which is a unified cache.
 - Used for both code and data.
- The L2 amount allocated to data & code varies dynamically, depending on the program being run.
 - If the program being run is more data intensive, then more of the L2 cache is allocated to data.


The x86 PC

Assembly Language, Design, and Interfacing

By Muhammad Ali Mazidi, Janice Gillespie Mazidi and Danny Causey

24.1: x86 PENTIUM® EVOLUTION level 3 cache - multicore

- In some high-performance systems designers place level 3 (L3) cache on the motherboard, outside the CPU, to speed up the external memory access
 - Between the CPU & DRAM



- L1 cache speed is a multiple of CPU speed, since a CPU retires multiple instructions per clock cycle.
- L2 cache works at the same speed as the CPU since it is on the same package.
- L3 cache works at a fraction of CPU speed as it is located outside the CPU package.

24.1: x86 PENTIUM® EVOLUTION cache evolution

Table 24-1: Pentium Cache Size and Speed

Product	Year	Transistors	CLK Speed	L1 Cache	L1 Cache	L2 Cache
			11-540%	(Code)	(Data)	
386	1985	275K	20 MHz	0	0	0
486	1989	1.2M	25 MHz	4 KB	4 KB	0
Pentium	1993	3.1M	60 MHz	8 KB	8 KB	0
Pentium Pro	1995	5.5M	200 MHz	8 KB	8 KB	0
Pentium II	1997	7M	266 MHz	16 KB	16 KB	256 KB
Pentium III	1999	8.2M	700 MHz	16 KB	16 KB	512 KB
Pentium IV	2000	42M	1.5 GHz	12 KB	8 KB	256 KB
Pentium M	2004	140M	2 GHz	32 KB	32 KB	2 MB
Pentium IV	2004	125M	3.4 GHz	12 KB	16 KB	1 MB
Pentium Duo	2006	152M	2.16 GHz	32 KB	32 KB	2 MB


Note: The clock speed is the speed at the time of introduction.

24.1: x86 PENTIUM® EVOLUTION Hyper-Threading Technology (HTT)

- In Pentium[®] IV, multithreaded execution was introduced.
 - A thread is a series of parallel programs that can run on different CPUs simultaneously.
 - In a multiprocessor environment, each is given its own CPU and memory.
 - Intel placed multiple CPUs into a single chip, and called it hyper-threading.
- As far as the OS is concerned, a CPU with hyperthreaded capability appears to be multiple logical CPUs inside a single physical CPU.

24.1: x86 PENTIUM® EVOLUTION Hyper-Threading Technology (HTT)

 In threaded CPUs, internal logical CPUs must share the system bus access.




Since both logical processors inside the hyper-threaded CPU use the same bus to accesses memory, they can get in each other's way and slow down program execution.


Fig. 24-3 Multithreading

The x86 PC

24.1: x86 PENTIUM® EVOLUTION Hyper-Threading Technology (HTT)

 When using multiple processors, each CPU has its own access to the system bus.





24.1: x86 PENTIUM® EVOLUTION Hyper-Threading Technology (HTT)

- In x86 literature, the words threads and tasks are used interchangeably.
 - There is a difference between a task and a thread.
- Multitasking runs multiple tasks all on a single CPU.
 - The CPU switches from one task to another in a circular fashion, giving each task a slice of the CPU's time.
- True multithreading attempts to parallelize execution of a single program in order to speed up the execution of that program.

24.1: x86 PENTIUM® EVOLUTION multicore technology


- Many newer-generation Pentiums® have what is called multicore technology.
 - Two or more independent processors (called cores) into a single chip.
 - Many x86 CPUs come with dual- and quad-core features, and work is being done on processors with 8 cores.
- In the *multicore* CPU there is one pathway to the system memory for the CPU
- In the *multiprocessor* CPUs each processor has its own memory space independent of the others.

The x86 PC

Assembly Language, Design, and Interfacing

By Muhammad Ali Mazidi, Janice Gillespie Mazidi and Danny Causey

24.1: x86 PENTIUM® EVOLUTION multicore technology






24.1: x86 PENTIUM® EVOLUTION Streaming SIMD Extension (SSE)

- Single instruction multiple data (SIMD) was first incorporated into the Pentium[®] Pro with the introduction of MMX technology.
 - The MMX used SIMD operations on packed bytes of data
- Intel expanded SIMD to include floating-point data, and called it streaming SIMD extension (SSE).
 - SSE was expanded further to include both single and double double-precision floating points.
 - Referred to as SSE, SSE2, SSE3, and SSSE3.
 - Original SIMD had one set of MMX registers.
 - Extended SIMD has several sets of MMX registers in addition to a new set of 128-bit registers called XMM.



24.1: x86 PENTIUM® EVOLUTION Streaming SIMD Extension (SSE)



See the entire SIMD extension table on page 631 of your textbook.

Fig. 24-6 SIMD Extension in x86 (Courtesy of Intel Corp.)

Assembly Language, Design, and Interfacing




The x86 PC

24.1: x86 PENTIUM® EVOLUTION other features of Pentium®

- Pentium® increased to 10 the number of pipeline stages, then 20, making a super-superpipeline CPU.
 - The instruction decoder units were expanded to four.
 - With a hugely expanded size of instruction queue.
- The enhancements were still insufficient to keep high-speed system designers happy, which left x86 CPU companies no choice but to expand the size of general-purpose registers to 64-bit.
 - The change to 64-bit architecture came about only when increase in performance of the 32-bit architecture was no longer possible.

24.2: 64-BIT PROCESSORS & VISTA FOR x86 64-bit architecture in x86

64-bit x86 processors needed to maintain compatibility with the earlier generations of 386 legacy software.





The x86 PC


24.2: 64-BIT PROCESSORS & VISTA FOR x86 64-bit architecture in x86

- To make the transition from 32- to 64-bit data types easier, 64-bit architecture can work in two modes:
 - Compatibility mode uses 8-, 16- & 32-bit data sizes and limits memory space to 4G bytes, like 386 architecture.
 - Most 16-bit & 32-bit legacy application software can be run without recompilation under 64-bit systems like Microsoft Vista.
 - 64-bit mode 386 registers AEX , EBX, etc., are expanded to 64-bit, and designated as RAX , RBX, etc.
 - Eight new 64-bit general purpose registers called R8–R15 were added, for a total of 16 64-bit registers.

The x86 PC

24.2: 64-BIT PROCESSORS & VISTA FOR x86 64-bit architecture in x86

The new 64-bit **R8–R15** registers can also be accessed as 8-bit, 16-bit, and 32-bit registers.





24.2: 64-BIT PROCESSORS & VISTA FOR x86 external memory of 64-bit architecture

- Pentium[®] 32-bit architecture limited the external memory space to 4G bytes.
 - It used segment registers to convert the linear addresses to physical addresses.
- 64-bit architecture largely stopped using segment registers, introducing a flat 264 byte memory space.
 - The EIP (instruction pointer) of the 386 has been expanded from 32-bit to 64-bit, and is called RIP.
 - It allows access of up to 264 bytes of code & data stored in external memory, using address A0–A63 pins.
 - A new 64-bit data pointer register allows access to external data memory using the A0–A63 address pins.



24.2: 64-BIT PROCESSORS & VISTA FOR x86 external memory of 64-bit architecture

- Not all family members have all the 64 address pins.
 - Many 64-bit x86 processors have only 36 pins (A0–A35).
 - Allows access of up to 64 G bytes of external memory.
- In 32-bit architectures, register sizes match the 32-bit external data bus.
 - In Pentium[®] Pro, the external data bus was expanded to 64-bit, even though the registers were left at 32-bit.
 - For the 64-bit registers, the external data bus is also 64-bit.
- To increase the bus bandwidth of the 64-bit x86 processors, 128 pins for the data bus is very likely.

24.2: 64-BIT PROCESSORS & VISTA FOR x86 x86 64-bit processors and Vista

- Both Intel & AMD have been producing 64-bit x86 processors since the early 2000s.
 - Microsoft used some aspects of the architecture in Windows XP and called it XP x64.
 - Only on introduction of Vista did Microsoft take full advantage of 64-bit architecture.
- Due to legacy software & the need for the transition to the new 64-bit systems, there are two versions:
 - Vista will run on any x86 32-bit architecture.
 - Vista x64 requires a 64-bit x86 processor and at least
 1G byte of DRAM on the motherboard.

24.2: 64-BIT PROCESSORS & VISTA FOR x86 Moore's Law

In the mid 1960s, Intel cofounder Gordon Moore predicted:

Table 24-2: Some 64-Bit Pr	ocessors in x8	6 Fam	"The number of transistors that		
Product	Year	Tr: W	would be incorporated on a silicon		
Xeon	2004		die would double every 18 months for the next several years."		
Xeon Processor MP	2005	J. Car			
Pentium 4	2005	9			
Pentium 840	2005	230	M 64 GB		
Dual-Core Xeon	2005	321	M 64 GB		
Pentium 4 672	2005	164	M 64 GB		
Pentium 955	2006	376	M 64 GB		
Core 2 X6800	2006	291	M 64 GB		
Xeon 5160	2006	291	M 64 GB		
Xeon 7140	2006	1.3	B 64 GB		
Core 2 QX6700	2006	582	M 64 GB		
Quad-Core Xeon 5355	2006	582	M 64 GB		

Note: For the registers associated with these 64-bit processors see Figure 24-6.

See the 64-bit x86 family on page 635 of your textbook.



Prentice Hall

Dec Hex Bin

24 18 00011000

ENDS; TWENTY-FOUR



The x86 PC

assembly language, design, and interfacing

fifth edition

MUHAMMAD ALI MAZIDI JANICE GILLISPIE MAZIDI DANNY CAUSEY