## hns3 devlink support

This document describes the devlink features implemented by the  ${\tt hns3}$  device driver.

The  ${\tt hns3}$  driver supports reloading via  ${\tt DEVLINK\_CMD\_RELOAD}.$ 

## Info versions

The  ${\tt hns3}$  driver reports the following versions devlink info versions implemented

Name	Type	Description
fw	running	Used to represent the firmware version.