Digital TV Common functions

Math functions

Provide some commonly-used math functions, usually required in order to estimate signal strength and signal to noise measurements in dB.

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\driver-api\media\[linux-master][Documentation][driver-api]
[media]dtv-common.rst, line 12)
Unknown directive type "kernel-doc".
.. kernel-doc:: include/media/dvb_math.h
```

DVB devices

Those functions are responsible for handling the DVB device nodes.

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\driver-api\media\[linux-master][Documentation][driver-api]
[media]dtv-common.rst, line 20)
Unknown directive type "kernel-doc".
.. kernel-doc:: include/media/dvbdev.h
```

Digital TV Ring buffer

Those routines implement ring buffers used to handle digital TV data and copy it from/to userspace.

Note

1. For performance reasons read and write routines don't check buffer sizes and/or number of bytes free/available. This has to be done before these routines are called. For example:

2. If there is exactly one reader and one writer, there is no need to lock read or write operations. Two or more readers must be locked against each other. Flushing the buffer counts as a read operation. Resetting the buffer counts as a read and write operation. Two or more writers must be locked against each other.

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-
master\Documentation\driver-api\media\[linux-master][Documentation][driver-api]
[media]dtv-common.rst, line 57)
Unknown directive type "kernel-doc".

.. kernel-doc:: include/media/dvb_ringbuffer.h
```

 $System\,Message: ERROR/3 \ (\mbox{D:\nonloarding-resources}) ample-onboarding-resources \ linux-master) [Documentation] [driver-api] [media] dtv-common.rst, line 62)$

Unknown directive type "kernel-doc".

.. kernel-doc:: include/media/dvb_vb2.h