VIDEO STILLPICTURE

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-
master\drivers\staging\media\av7110\[linux-master][drivers][staging][media]
[av7110]video-stillpicture.rst, line 2)
Unknown directive type "cnamespace".
.. c:namespace:: DTV.video
```

Name

VIDEO_STILLPICTURE

```
Attention!
```

This ioctl is deprecated.

Synopsis

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\[linux-master][drivers][staging][media]
[av7110]video-stillpicture.rst, line 20)
Unknown directive type "cmacro".
.. c:macro:: VIDEO_STILLPICTURE
```

int ioctl(fd, VIDEO_STILLPICTURE, struct video_still_picture *sp)

Arguments

```
System\ Message: ERROR/3\ (\texttt{D:\nboarding-resources}) sample-onboarding-resources \verb|\linux-resources|| in ux-resources | in ux-resources|| in ux-resources
master\drivers\staging\media\av7110\[linux-master][drivers][staging][media]
 [av7110] video-still picture.rst, line 27)
Unknown directive type "flat-table".
                 .. flat-table::
                                   :header-rows: 0
                                   :stub-columns: 0
                                     - .. row 1
                                                - int fd
                                                - File descriptor returned by a previous call to open().
                                   - .. row 2
                                                - int request
                                                - Equals VIDEO_STILLPICTURE for this command.
                                   - .. row 3
                                                 - struct video still_picture \*sp
                                                - Pointer to a location where an I-frame and size is stored.
```

Description

This ioctl call asks the Video Device to display a still picture (I-frame). The input data shall contain an I-frame. If the pointer is NULL, then the current displayed still picture is blanked.

Keturn Value

On success 0 is returned, on error -1 and the errno variable is set appropriately. The generic error codes are described at the ref. Generic Error Codes < gen-errors > ` chapter.

 $System\,Message: ERROR/3 \ (\c : \c sample-onboarding-resources \end{continuous} \ aster \drivers \staging \end{continuous} \ [av7110] \ [av7110] \ video-still picture.rst, line 59); \ backlink$

Unknown interpreted text role 'ref'.