VIDEO GET SIZE

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\[linux-master][drivers][staging][media]
[av7110]video-get-size.rst, line 2)
Unknown directive type "cnamespace".
.. c:namespace:: DTV.video
```

Name

VIDEO_GET_SIZE

```
Attention!
```

This ioctl is deprecated.

Synopsis

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\[linux-master][drivers][staging][media]
[av7110]video-get-size.rst, line 20)
Unknown directive type "cmacro".
.. c:macro:: VIDEO_GET_SIZE
```

int ioctl(int fd, VIDEO_GET_SIZE, video_size_t *size)

Arguments

```
System\ Message: ERROR/3\ (\texttt{D:\nboarding-resources}) sample-onboarding-resources \verb|\linux-resources|| in ux-resources | the property of the
master\drivers\staging\media\av7110\[linux-master][drivers][staging][media]
 [av7110] video-get-size.rst, line 27)
Unknown directive type "flat-table".
                  .. flat-table::
                                      :header-rows:
                                      :stub-columns: 0
                                       - .. row 1
                                                    - int fd
                                                    - File descriptor returned by a previous call to open().
                                      - .. row 2
                                                    - int request
                                                    - Equals VIDEO_GET_SIZE for this command.
                                      - .. row 3
                                                     - video size t \*size
                                                    - Returns the size and aspect ratio.
```

Description

This ioctl returns the size and aspect ratio.

```
master\drivers\staging\media\av7110\[linux-master][drivers][staging][media]
[av7110]video-get-size.rst, line 54)
Unknown directive type "c:type".
... c:type:: video_size_t
```

Return Value

On success 0 is returned, on error -1 and the errno variable is set appropriately. The generic error codes are described at the ref. Generic Error Codes <gen-errors>` chapter.

 $System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\[linux-master][drivers][staging][media] [av7110]video-get-size.rst, line 67); backlink$

Unknown interpreted text role 'ref'.