# **AUDIO SET STREAMTYPE**

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-
master\drivers\staging\media\av7110\[linux-master][drivers][staging][media]
[av7110]audio-set-streamtype.rst, line 2)
Unknown directive type "cnamespace".
.. c:namespace:: DTV.audio
```

#### Name

AUDIO\_SET\_STREAMTYPE

```
Attention!
This ioctl is deprecated
```

### **Synopsis**

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\[linux-master][drivers][staging][media]
[av7110]audio-set-streamtype.rst, line 20)
Unknown directive type "cmacro".
.. c:macro:: AUDIO_SET_STREAMTYPE
```

int ioctl(fd, AUDIO SET STREAMTYPE, int type)

#### **Arguments**

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-
master\drivers\staging\media\av7110\[linux-master][drivers][staging][media]
[av7110] audio-set-streamtype.rst, line 27)

Unknown directive type "flat-table".

.. flat-table::
    :header-rows: 0
    :stub-columns: 0

-
    - int fd

- File descriptor returned by a previous call to open().

-
    - int type
    - stream type
```

## **Description**

This is useful if the stream offers several audio sub-streams like LPCM and AC3.

#### Return Value

On success 0 is returned, on error -1 and the errno variable is set appropriately. The generic error codes are described at the ref. Generic Error Codes <gen-errors>` chapter.

Unknown interpreted text role 'ref'.

 $System\ Message: ERROR/3\ (\texttt{D:\noboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\[linux-master]\ [drivers]\ [staging]\ [media]\ [av7110]\ audio-set-streamtype.rst, line\ 58)$ 

Unknown directive type "flat-table".

```
.. flat-table::
    :header-rows: 0
    :stub-columns: 0

-    .. row 1
    - ``EINVAL``
    - type is not a valid or supported stream type.
```