User Controls

Devices typically have a number of user-settable controls such as brightness, saturation and so on, which would be presented to the user on a graphical user interface. But, different devices will have different controls available, and furthermore, the range of possible values, and the default value will vary from device to device. The control ioctls provide the information and a mechanism to create a nice user interface for these controls that will work correctly with any device.

All controls are accessed using an ID value. V4L2 defines several IDs for specific purposes. Drivers can also implement their own custom controls using $V4L2_CID_PRIVATE_BASE$ [1] and higher values. The pre-defined control IDs have the prefix $V4L2_CID_$, and are listed in ref. control-id. The ID is used when querying the attributes of a control, and when getting or setting the current value.

```
System \, Message: ERROR/3 \, (\mbox{D:\non-resources}) ample-onboarding-resources $$\lim \mbox{master\non-resources}$ in waster\non-resources $$\lim \mbox{V41\[linux-master]} [\mbox{Documentation}] [\mbox{userspace-api}] [\mbox{media}] [\mbox{V41}] control.rst, $$\lim 18$); $$backlink$ $$
```

Unknown interpreted text role "ref".

Generally applications should present controls to the user without assumptions about their purpose. Each control comes with a name string the user is supposed to understand. When the purpose is non-intuitive the driver writer should provide a user manual, a user interface plug-in or a driver specific panel application. Predefined IDs were introduced to change a few controls programmatically, for example to mute a device during a channel switch.

Drivers may enumerate different controls after switching the current video input or output, tuner or modulator, or audio input or output. Different in the sense of other bounds, another default and current value, step size or other menu items. A control with a certain *custom* ID can also change name and type.

If a control is not applicable to the current configuration of the device (for example, it doesn't apply to the current video input) drivers set the V4L2 CTRL FLAG INACTIVE flag.

Control values are stored globally, they do not change when switching except to stay within the reported bounds. They also do not change e. g. when the device is opened or closed, when the tuner radio frequency is changed or generally never without application request.

V4L2 specifies an event mechanism to notify applications when controls change value (see ref": VIDIOC_SUBSCRIBE_EVENT, event v4L2 EVENT CTRL), panel applications might want to make use of that in order to always reflect the correct control value.

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] control.rst, line 48); backlink
```

Unknown interpreted text role "ref".

All controls use machine endianness.

Control IDs

```
V4L2_CID_BASE

First predefined ID, equal to V4L2_CID_BRIGHTNESS.

V4L2_CID_USER_BASE

Synonym of V4L2_CID_BASE.

V4L2_CID_BRIGHTNESS (integer)

Picture brightness, or more precisely, the black level.

V4L2_CID_CONTRAST (integer)

Picture contrast or luma gain.

V4L2_CID_SATURATION (integer)

Picture color saturation or chroma gain.

V4L2_CID_HUE (integer)

Hue or color balance.

V4L2_CID_AUDIO_VOLUME (integer)
```

Overall audio volume. Note some drivers also provide an OSS or ALSA mixer interface.

V4L2_CID_AUDIO_BALANCE (integer)

Audio stereo balance. Minimum corresponds to all the way left, maximum to right.

V4L2 CID AUDIO BASS (integer)

Audio bass adjustment.

V4L2_CID_AUDIO_TREBLE (integer)

Audio treble adjustment.

V4L2 CID AUDIO MUTE (boolean)

Mute audio, i. e. set the volume to zero, however without affecting $V4L2_CID_AUDIO_VOLUME$. Like ALSA drivers, V4L2 drivers must mute at load time to avoid excessive noise. Actually the entire device should be reset to a low power consumption state.

V4L2 CID AUDIO LOUDNESS (boolean)

Loudness mode (bass boost).

V4L2 CID BLACK LEVEL (integer)

Another name for brightness (not a synonym of V4L2_CID_BRIGHTNESS). This control is deprecated and should not be used in new drivers and applications.

V4L2_CID_AUTO_WHITE_BALANCE (boolean)

Automatic white balance (cameras).

V4L2 CID DO WHITE BALANCE (button)

This is an action control. When set (the value is ignored), the device will do a white balance and then hold the current setting. Contrast this with the boolean V4L2_CID_AUTO_WHITE_BALANCE, which, when activated, keeps adjusting the white balance.

V4L2 CID RED BALANCE (integer)

Red chroma balance.

V4L2_CID_BLUE_BALANCE (integer)

Blue chroma balance.

V4L2 CID GAMMA (integer)

Gamma adjust.

V4L2 CID WHITENESS (integer)

Whiteness for grey-scale devices. This is a synonym for V4L2_CID_GAMMA. This control is deprecated and should not be used in new drivers and applications.

V4L2 CID EXPOSURE (integer)

Exposure (cameras). [Unit?]

V4L2 CID AUTOGAIN (boolean)

Automatic gain/exposure control.

V4L2 CID GAIN (integer)

Gain control.

Primarily used to control gain on e.g. TV tuners but also on webcams. Most devices control only digital gain with this control but on some this could include analogue gain as well. Devices that recognise the difference between digital and analogue gain use controls V4L2 CID DIGITAL GAIN and V4L2 CID ANALOGUE GAIN.

V4L2 CID HFLIP (boolean)

Mirror the picture horizontally.

V4L2_CID_VFLIP (boolean)

Mirror the picture vertically.

V4L2_CID_POWER_LINE_FREQUENCY (enum)

Enables a power line frequency filter to avoid flicker. Possible values for enum v412 power line frequency are:

V4L2_CID_POWER_LINE_FREQUENCY_DISABLED	0
V4L2_CID_POWER_LINE_FREQUENCY_50HZ	1
V4L2_CID_POWER_LINE_FREQUENCY_60HZ	2
V4L2_CID_POWER_LINE_FREQUENCY_AUTO	3

Enables automatic hue control by the device. The effect of setting $V4L2_CID_HUE$ while automatic hue control is enabled is undefined, drivers should ignore such request.

```
V4L2 CID WHITE BALANCE TEMPERATURE (integer)
```

This control specifies the white balance settings as a color temperature in Kelvin. A driver should have a minimum of 2800 (incandescent) to 6500 (daylight). For more information about color temperature see Wikipedia.

```
V4L2 CID SHARPNESS (integer)
```

Adjusts the sharpness filters in a camera. The minimum value disables the filters, higher values give a sharper picture.

```
V4L2 CID BACKLIGHT COMPENSATION (integer)
```

Adjusts the backlight compensation in a camera. The minimum value disables backlight compensation.

```
V4L2 CID CHROMA AGC (boolean)
```

Chroma automatic gain control.

```
V4L2 CID CHROMA GAIN (integer)
```

Adjusts the Chroma gain control (for use when chroma AGC is disabled).

```
V4L2 CID COLOR KILLER (boolean)
```

Enable the color killer (i. e. force a black & white image in case of a weak video signal).

```
V4L2 CID COLORFX (enum)
```

Selects a color effect. The following values are defined:

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master][Documentation][userspace-api][media][v41]control.rst, line 203)

Unknown directive type "tabularcolumns".

.. tabularcolumns:: |p{5.7cm}|p{11.8cm}|
```

Unknown directive type "flat-table".

```
.. flat-table::
   :header-rows:
   :stub-columns: 0
   :widths: 11 24
   * - ``V4L2 COLORFX_NONE``
     - Color effect is disabled.
   * - ``V4L2 COLORFX ANTIQUE
     - An aging (old photo) effect.
   * - ``V4L2 COLORFX_ART_FREEZE`
     - Frost color effect.
   * - ``V4L2 COLORFX AQUA`
     - Water color, cool tone.
   * - ``V4L2 COLORFX BW
     - Black and white.
   * - ``V4L2 COLORFX EMBOSS`
     - Emboss, the highlights and shadows replace light/dark boundaries
       and low contrast areas are set to a gray background.
   * - ``V4L2 COLORFX GRASS GREEN`
     - Grass green.
   * - ``V4L2 COLORFX NEGATIVE``
     - Negative.
   * - ``V4L2 COLORFX SEPIA``
     - Sepia tone.
   * - ``V4L2 COLORFX SKETCH``
     - Sketch.
        ``V4L2 COLORFX SKIN WHITEN``
     - Skin whiten.
   * - ``V4L2 COLORFX_SKY_BLUE``
      - Sky blue.
    * - ``V4L2 COLORFX SOLARIZATION``
     - Solarization, the image is partially reversed in tone, only color
       values above or below a certain threshold are inverted.
   * - ``V4L2 COLORFX_SILHOUETTE`
     - Silhouette (outline).
```

- * ``V4L2_COLORFX_VIVID``
 - Vivid colors.
- * ``V4L2_COLORFX_SET_CBCR``
 - The Cb and Cr chroma components are replaced by fixed coefficients determined by ``V4L2 CID COLORFX_CBCR`` control.
- * ``V4L2 COLORFX SET RGB``
 - The RGB components are replaced by the fixed RGB components determined by ``V4L2 CID COLORFX RGB`` control.

V4L2_CID_COLORFX_RGB (integer)

Determines the Red, Green, and Blue coefficients for $V4L2_COLORFX_SET_RGB$ color effect. Bits [7:0] of the supplied 32 bit value are interpreted as Blue component, bits [15:8] as Green component, bits [23:16] as Red component, and bits [31:24] must be zero.

V4L2 CID COLORFX CBCR (integer)

Determines the Cb and Cr coefficients for V4L2_COLORFX_SET_CBCR color effect. Bits [7:0] of the supplied 32 bit value are interpreted as Cr component, bits [15:8] as Cb component and bits [31:16] must be zero.

V4L2_CID_AUTOBRIGHTNESS (boolean)

Enable Automatic Brightness.

V4L2 CID ROTATE (integer)

Rotates the image by specified angle. Common angles are 90, 270 and 180. Rotating the image to 90 and 270 will reverse the height and width of the display window. It is necessary to set the new height and width of the picture using the ref. VIDIOC S FMT < VIDIOC G FMT> ioctl according to the rotation angle selected.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master]
[Documentation] [userspace-api] [media] [v41] control.rst, line 267); backlink

Unknown interpreted text role "ref".

V4L2_CID_BG_COLOR (integer)

Sets the background color on the current output device. Background color needs to be specified in the RGB24 format. The supplied 32 bit value is interpreted as bits 0-7 Red color information, bits 8-15 Green color information, bits 16-23 Blue color information and bits 24-31 must be zero.

V4L2_CID_ILLUMINATORS_1 V4L2_CID_ILLUMINATORS_2 (boolean)

Switch on or off the illuminator 1 or 2 of the device (usually a microscope).

V4L2 CID MIN BUFFERS FOR CAPTURE (integer)

This is a read-only control that can be read by the application and used as a hint to determine the number of CAPTURE buffers to pass to REQBUFS. The value is the minimum number of CAPTURE buffers that is necessary for hardware to work.

V4L2_CID_MIN_BUFFERS_FOR_OUTPUT (integer)

This is a read-only control that can be read by the application and used as a hint to determine the number of OUTPUT buffers to pass to REQBUFS. The value is the minimum number of OUTPUT buffers that is necessary for hardware to work.

V4L2 CID ALPHA COMPONENT (integer)

Sets the alpha color component. When a capture device (or capture queue of a mem-to-mem device) produces a frame format that includes an alpha component (e.g. ref: packed RGB image formats <pixfint-rgb>') and the alpha value is not defined by the device or the mem-to-mem input data this control lets you select the alpha component value of all pixels. When an output device (or output queue of a mem-to-mem device) consumes a frame format that doesn't include an alpha component and the device supports alpha channel processing this control lets you set the alpha component value of all pixels for further processing in the device.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] control.rst, line 300); backlink

Unknown interpreted text role "ref".

End of the predefined control IDs (currently V4L2 CID ALPHA COMPONENT + 1).

```
V4L2 CID PRIVATE BASE
```

ID of the first custom (driver specific) control. Applications depending on particular custom controls should check the driver name and version, see reff querycap.

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master]
[Documentation] [userspace-api] [media] [v41] control.rst, line 317); backlink
Unknown interpreted text role "ref".
```

Applications can enumerate the available controls with the ref: VIDIOC_QUERYCTRL and ref: VIDIOC_GCTRL and ref: VIDIOC_GCTRL ioctls, get and set a control value with the ref: VIDIOC_GCTRL ioctls. Drivers must implement YIDIOC_GCTRL and YIDIOC_GCTRL ioctls. Drivers must implement YIDIOC_GCTRL and YIDIOC_GCTRL and YIDIOC_GCTRL when the device has one or more controls, YIDIOC_QUERYMENU when it has one or more menu type controls.

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master][Documentation][userspace-api][media][v41]control.rst, line 321); backlink
Unknown interpreted text role "ref".
```

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master][Documentation][userspace-api][media][v41]control.rst, line 321); backlink

Unknown interpreted text role 'ref'.
```

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master][Documentation][userspace-api][media][v41]control.rst, line 321); backlink
Unknown interpreted text role "ref".
```

Unknown interpreted text role 'ref'.

Example: Enumerating all controls

```
struct v412 queryctrl queryctrl;
struct v412_querymenu querymenu;
static void enumerate_menu(__u32 id)
   printf(" Menu items:\\n");
   memset(&querymenu, 0, sizeof(querymenu));
   querymenu.id = id;
    for (querymenu.index = queryctrl.minimum;
        querymenu.index <= queryctrl.maximum;</pre>
        querymenu.index++) {
        if (0 == ioctl(fd, VIDIOC_QUERYMENU, &querymenu)) {
           printf(" %s\\n", querymenu.name);
        }
    }
memset(&queryctrl, 0, sizeof(queryctrl));
queryctrl.id = V4L2 CTRL FLAG NEXT CTRL;
while (0 == ioctl(fd, VIDIOC QUERYCTRL, &queryctrl)) {
    if (!(queryctrl.flags & V4L2 CTRL FLAG DISABLED)) {
       printf("Control %s\\n", queryctrl.name);
        if (queryctrl.type == V4L2 CTRL TYPE MENU)
```

```
enumerate_menu(queryctrl.id);
}

queryctrl.id |= V4L2_CTRL_FLAG_NEXT_CTRL;
}
if (errno != EINVAL) {
    perror("VIDIOC_QUERYCTRL");
    exit(EXIT_FAILURE);
}
```

Example: Enumerating all controls including compound controls

Example: Enumerating all user controls (old style)

```
memset(&queryctrl, 0, sizeof(queryctrl));
for (queryctrl.id = V4L2 CID BASE;
    queryctrl.id < V4L2 CID LASTP1;
     queryctrl.id++) {
    if (0 == ioctl(fd, VIDIOC_QUERYCTRL, &queryctrl)) {
        if (queryctrl.flags & V4L2 CTRL FLAG DISABLED)
            continue;
       printf("Control %s\\n", queryctrl.name);
        if (queryctrl.type == V4L2 CTRL TYPE MENU)
           enumerate_menu(queryctrl.id);
    } else {
       if (errno == EINVAL)
            continue;
       perror("VIDIOC QUERYCTRL");
       exit(EXIT FAILURE);
for (queryctrl.id = V4L2_CID_PRIVATE_BASE;;
    queryctrl.id++) {
    if (0 == ioctl(fd, VIDIOC_QUERYCTRL, &queryctrl)) {
        if (queryctrl.flags & V4L2 CTRL FLAG DISABLED)
            continue:
       printf("Control %s\\n", queryctrl.name);
        if (queryctrl.type == V4L2 CTRL TYPE MENU)
           enumerate_menu(queryctrl.id);
       if (errno == EINVAL)
           break;
       perror("VIDIOC QUERYCTRL");
       exit(EXIT FAILURE);
```

Example: Changing controls

```
struct v412 control control;
memset(&queryctrl, 0, sizeof(queryctrl));
queryctrl.id = V4L2 CID BRIGHTNESS;
if (-1 == ioctl(fd, VIDIOC QUERYCTRL, &queryctrl)) {
   if (errno != EINVAL) {
       perror("VIDIOC QUERYCTRL");
       exit(EXIT FAILURE);
    } else {
       printf("V4L2 CID BRIGHTNESS is not supportedn");
} else if (queryctrl.flags & V4L2 CTRL FLAG DISABLED) {
   printf("V4L2_CID_BRIGHTNESS is not supportedn");
} else {
   memset(&control, 0, sizeof (control));
   control.id = V4L2 CID BRIGHTNESS;
   control.value = queryctrl.default value;
   if (-1 == ioctl(fd, VIDIOC S CTRL, &control)) {
       perror("VIDIOC S CTRL");
        exit(EXIT_FAILURE);
}
memset(&control, 0, sizeof(control));
control.id = V4L2 CID CONTRAST;
if (0 == ioctl(fd, VIDIOC G CTRL, &control)) {
   control.value += 1;
    /* The driver may clamp the value or return ERANGE, ignored here */
   if (-1 == ioctl(fd, VIDIOC S CTRL, &control)
       && errno != ERANGE) {
       perror("VIDIOC S CTRL");
       exit(EXIT FAILURE);
   }
/* Ignore if V4L2 CID CONTRAST is unsupported */
} else if (errno != EINVAL) {
   perror("VIDIOC G CTRL");
   exit(EXIT FAILURE);
control.id = V4L2 CID AUDIO MUTE;
control.value = 1; /* silence */
/* Errors ignored */
ioctl(fd, VIDIOC S CTRL, &control);
```

[1] The use of V4L2_CID_PRIVATE_BASE is problematic because different drivers may use the same V4L2_CID_PRIVATE_BASE ID for different controls. This makes it hard to programmatically set such controls since the meaning of the control with that ID is driver dependent. In order to resolve this drivers use unique IDs and the V4L2_CID_PRIVATE_BASE IDs are mapped to those unique IDs by the kernel. Consider these V4L2_CID_PRIVATE_BASE IDs as aliases to the real IDs.

Many applications today still use the V4L2_CID_PRIVATE_BASE IDs instead of using ref. VIDIOC_QUERYCTRL with the V4L2_CTRL_FLAG_NEXT_CTRL flag to enumerate all IDs, so support for V4L2_CID_PRIVATE_BASE is still around.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master]
[Documentation] [userspace-api] [media] [v41] control.rst, line 514); backlink
Unknown interpreted text role "ref".