# Video Capture Interface

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 2)

Unknown directive type "c:namespace".

.. c:namespace:: V4L

Video capture devices sample an analog video signal and store the digitized images in memory. Today nearly all devices can capture at full 25 or 30 frames/second. With this interface applications can control the capture process and move images from the driver into user space.

Conventionally V4L2 video capture devices are accessed through character device special files named /dev/video and /dev/video to /dev/video with major number 81 and minor numbers 0 to 63. /dev/video is typically a symbolic link to the preferred video device.

Note

The same device file names are used for video output devices.

### **Querying Capabilities**

Devices supporting the video capture interface set the <code>V4L2\_CAP\_VIDEO\_CAPTURE</code> or <code>V4L2\_CAP\_VIDEO\_CAPTURE</code> or <code>V4L2\_CAP\_VIDEO\_CAPTURE</code> mplane flag in the <code>capabilities</code> field of struct <code>c.type:'v4l2\_capability'</code> returned by the <code>ref.'VIDIOC\_QUERYCAP'</code> ioctl. As secondary device functions they may also support the <code>ref.'video</code> overlay <code>overlay</code> (<code>V4L2\_CAP\_VIDEO\_OVERLAY</code>) and the <code>ref.'raw VBI</code> capture <code>raw-vbi</code> (<code>V4L2\_CAP\_VBI\_CAPTURE</code>) interface. At least one of the read/write or streaming I/O methods must be supported. Tuners and audio inputs are optional.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41]dev-capture.rst, line 26); backlink

Unknown interpreted text role "c:type".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 26); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 26); backlink

Unknown interpreted text role "ref".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 26); backlink

Unknown interpreted text role "ref".

## **Supplemental Functions**

Video capture devices shall support ref audio input <audio>', ref 'tuner', ref 'control>', ref 'cropping and scaling <crop>' and ref 'streaming parameter <streaming-par>' ioctls as needed. The ref 'video input <video>' ioctls must be supported by all video capture devices.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api\media\v41\[linux-master]]

```
api] [media] [v41] dev-capture.rst, line 40); backlink Unknown interpreted text role 'ref'.
```

 $System\ Message: ERROR/3\ (\texttt{D:\noboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master]\ [Documentation]\ [userspace-api]\ [media]\ [v41]\ dev-capture.rst,\ line\ 40);\ backlink$ 

Unknown interpreted text role "ref".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 40); backlink

Unknown interpreted text role 'ref'.

 $System \, Message: ERROR/3 \, (\texttt{D:\noboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\mbox{\scalebox} [linux-master] \, [Documentation] \, [userspace-api] \, [media] \, [v41] \, dev-capture.rst, \, line \, 40); \, backlink \, (backlink) \, (backlin$ 

Unknown interpreted text role "ref".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 40); backlink

Unknown interpreted text role "ref".

 $System\ Message: ERROR/3\ (\texttt{D:\noboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master\]\ [Documentation\]\ [userspace-api\]\ [media\]\ [v41\]\ dev-capture.rst, line\ 40); \ backlink$ 

Unknown interpreted text role 'ref'.

### **Image Format Negotiation**

The result of a capture operation is determined by cropping and image format parameters. The former select an area of the video picture to capture, the latter how images are stored in memory, i. e. in RGB or YUV format, the number of bits per pixel or width and height. Together they also define how images are scaled in the process.

As usual these parameters are *not* reset at :c:func:`open()` time to permit Unix tool chains, programming a device and then reading from it as if it was a plain file. Well written V4L2 applications ensure they really get what they want, including cropping and scaling.

 $System\ Message: ERROR/3\ (D:\onboarding-resources\space-onboarding-resources\label{linux-master}) In user space-api [linux-master] [Documentation] [user space-api] [media] [v41] dev-capture.rst, line 56); backlink$ 

Unknown interpreted text role "c:func".

Cropping initialization at minimum requires to reset the parameters to defaults. An example is given in refi crop.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master][Documentation][userspace-api][media][v41]dev-capture.rst, line 61); backlink

Unknown interpreted text role 'ref'.

To query the current image format applications set the type field of a struct :c:type:'v4l2\_format' to V4L2\_BUF\_TYPE\_VIDEO\_CAPTURE or V4L2\_BUF\_TYPE\_VIDEO\_CAPTURE MPLANE and call the ref:'VIDIOC\_G\_FMT 
 VIDIOC\_G\_FMT>' ioctl with a pointer to this structure. Drivers fill the struct :c:type:'v4l2\_pix\_format' pix or the struct :c:type:'v4l2\_pix\_format\_mplane' pix\_mp member of the fmt union.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41]dev-capture.rst, line 64); backlink

Unknown interpreted text role "c:type".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 64); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41]dev-capture.rst, line 64); backlink

Unknown interpreted text role "c:type".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 64); backlink

Unknown interpreted text role "c:type".

To request different parameters applications set the <code>type</code> field of a struct <code>:c:type:'v4l2\_format'</code> as above and initialize all fields of the struct <code>:c:type:'v4l2\_pix\_format'</code> <code>vbi</code> member of the <code>fmt</code> union, or better just modify the results of <code>:ref:'VIDIOC\_G\_FMT'</code> <VIDIOC\_G\_FMT>', and call the <code>:ref:'VIDIOC\_S\_FMT <VIDIOC\_G\_FMT>'</code> ioctl with a pointer to this structure. Drivers may adjust the parameters and finally return the actual parameters as <code>:ref:'VIDIOC\_G\_FMT <VIDIOC\_G\_FMT>'</code> does.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 74); backlink

Unknown interpreted text role "c:type".

 $System\,Message: ERROR/3~(\texttt{D:\noboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master\]~[Documentation\]~[userspace-api\]~[media]~[v41]~dev-capture.rst, line~74); backlink$ 

Unknown interpreted text role "c:type".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41]dev-capture.rst, line 74); backlink

Unknown interpreted text role "ref".

 $System\ Message: ERROR/3\ (\texttt{D:\noboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master]\ [Documentation]\ [userspace-api]\ [media]\ [v41]\ dev-capture.rst, line\ 74); backlink$ 

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 74); backlink

Unknown interpreted text role 'ref'.

Like ref: VIDIOC\_S\_FMT < VIDIOC\_G\_FMT>` the ref: VIDIOC\_TRY\_FMT < VIDIOC\_G\_FMT>` ioctl can be used to learn about hardware limitations without disabling I/O or possibly time consuming hardware preparations.

 $System\ Message: ERROR/3\ (\texttt{D:\noboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master\]\ [Documentation\]\ [userspace-api\media\]\ [w41\]\ dev-capture.rst, line\ 83); \ backlink$ 

Unknown interpreted text role "ref".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 83); backlink

Unknown interpreted text role 'ref'.

The contents of struct :c:type:'v4l2\_pix\_format' and struct :c:type:'v4l2\_pix\_format\_mplane' are discussed in :ref':pixfint'. See also the specification of the :ref:'VIDIOC\_G\_FMT<VIDIOC\_G\_FMT>', :ref:'VIDIOC\_S\_FMT<VIDIOC\_G\_FMT>' and :ref:'VIDIOC\_TRY\_FMT

ref:'VIDIOC\_TRY\_FMT
-VIDIOC\_G\_FMT> ioctls for details. Video capture devices must implement both the :ref:'VIDIOC\_G\_FMT> ioctl., even if :ref:'VIDIOC\_S\_FMT

ref:'VIDIOC\_S\_FMT
-VIDIOC\_G\_FMT> ignores all requests and always returns default parameters as :ref:'VIDIOC\_G\_FMT> ioctl., even if :ref:'VIDIOC\_G\_FMT> ioctl., even ioctl.

 $System\ Message: ERROR/3\ (\texttt{D:\noboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master\]\ [Documentation\]\ [userspace-api\]\ [media\]\ [v41\]\ dev-capture.rst,\ line\ 87);\ backlink$ 

Unknown interpreted text role "c:type".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 87); backlink

Unknown interpreted text role "c:type".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 87); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 87); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 87); backlink

Unknown interpreted text role "ref".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 87); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master][Documentation][userspace-api][media][v41]dev-capture.rst, line 87); backlink

Unknown interpreted text role "ref".

 $System\ Message: ERROR/3\ (\texttt{D:\noboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master\]\ [Documentation\]\ [userspace-api\]\ [media\]\ [v41\]\ dev-capture.rst, line\ 87); backlink$ 

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 87); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 87); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 87); backlink

Unknown interpreted text role 'ref'.

### **Reading Images**

A video capture device may support the ref: read() function < func-read>` and/or streaming (ref: memory mapping < func-mmap>` or ref: user pointer < userp>`) I/O. See ref: io` for details.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] dev-capture.rst, line 99); backlink

Unknown interpreted text role 'ref'.

 $System\ Message: ERROR/3\ (\mbox{D:\noboarding-resources}\scample-onboarding-resources\linux-master)\ [Documentation]\ [userspace-api]\ [media]\ [v41]\ dev-capture.rst,\ line\ 99); \ backlink$ 

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master][Documentation][userspace-api][media][v41]dev-capture.rst, line 99); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41]dev-capture.rst, line 99); backlink

Unknown interpreted text role 'ref'.