Digital Video Control Reference

The Digital Video control class is intended to control receivers and transmitters for VGA, DVI (Digital Visual Interface), HDMI (ref. hdmi) and DisplayPort (ref. dp). These controls are generally expected to be private to the receiver or transmitter subdevice that implements them, so they are only exposed on the /dev/v4l-subdev* device node.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41]ext-ctrls-dv.rst, line 9); backlink

Unknown interpreted text role "ref".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41]ext-ctrls-dv.rst, line 9); backlink

Unknown interpreted text role 'ref'.

Note

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] ext-ctrls-dv.rst, line 19); backlink Unknown interpreted text role "ref".

 $System\ Message: ERROR/3\ (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master\] [Documentation]\ [userspace-api]\ [media]\ [v41]\ext-ctrls-dv.rst, line\ 19); backlink$

Unknown interpreted text role 'ref'.

These pads appear in several of the controls in this section as bitmasks, one bit for each pad. Bit 0 corresponds to pad 0, bit 1 to pad 1, etc. The maximum value of the control is the set of valid pads.

Digital Video Control IDs

```
V4L2 CID DV CLASS (class)
```

The Digital Video class descriptor.

```
V4L2 CID DV TX HOTPLUG (bitmask)
```

Many connectors have a hotplug pin which is high if EDID information is available from the source. This control shows the state of the hotplug pin as seen by the transmitter. Each bit corresponds to an output pad on the transmitter. If an output pad does not have an associated hotplug pin, then the bit for that pad will be 0. This read-only control is applicable to DVI-D, HDMI and DisplayPort connectors.

```
V4L2 CID DV TX RXSENSE (bitmask)
```

Rx Sense is the detection of pull-ups on the TMDS clock lines. This normally means that the sink has left/entered standby (i.e. the transmitter can sense that the receiver is ready to receive video). Each bit corresponds to an output pad on the transmitter. If an output pad does not have an associated Rx Sense, then the bit for that pad will be 0. This read-only control is applicable to DVI-D and HDMI devices.

```
V4L2_CID_DV_TX_EDID_PRESENT (bitmask)
```

When the transmitter sees the hotplug signal from the receiver it will attempt to read the EDID. If set, then the transmitter has read at least the first block (= 128 bytes). Each bit corresponds to an output pad on the transmitter. If an output pad does not support EDIDs, then the bit for that pad will be 0. This read-only control is applicable to VGA, DVI-A/D, HDMI

```
and DisplayPort connectors.
```

```
V4L2_CID_DV_TX_MODE
```

(enum)

enum v412 dv tx mode -

HDMI transmitters can transmit in DVI-D mode (just video) or in HDMI mode (video + audio + auxiliary data). This control selects which mode to use: V4L2_DV_TX_MODE_DVI_D or V4L2_DV_TX_MODE_HDMI. This control is applicable to HDMI connectors.

```
V4L2_CID_DV_TX_RGB_RANGE
(enum)
enum v4l2 dv rgb range -
```

Select the quantization range for RGB output. V4L2_DV_RANGE_AUTO follows the RGB quantization range specified in the standard for the video interface (ie. ref. cea861 for HDMI). V4L2_DV_RANGE_LIMITED and V4L2_DV_RANGE_FULL override the standard to be compatible with sinks that have not implemented the standard correctly (unfortunately quite common for HDMI and DVI-D). Full range allows all possible values to be used whereas limited range sets the range to (16 << (N-8)) - (235 << (N-8)) where N is the number of bits per component. This control is applicable to VGA, DVI-A/D, HDMI and DisplayPort connectors.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master]
[Documentation] [userspace-api] [media] [v41] ext-ctrls-dv.rst, line 80); backlink

Unknown interpreted text role 'ref'.

Configures the IT Content Type of the transmitted video. This information is sent over HDMI and DisplayPort connectors as part of the AVI InfoFrame. The term 'IT Content' is used for content that originates from a computer as opposed to content from a TV broadcast or an analog source. The enum v412 dv it content type defines the possible content types:

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] ext-ctrls-dv.rst, line 102)

Unknown directive type "tabularcolumns".

.. tabularcolumns:: $|p{7.3cm}|p{10.2cm}|$

Unknown directive type "flat-table".

```
.. flat-table::
   :header-rows:
   :stub-columns: 0
   * - ``V4L2_DV_IT_CONTENT_TYPE_GRAPHICS``
     - Graphics content. Pixel data should be passed unfiltered and
       without analog reconstruction.
    * - ``V4L2 DV IT CONTENT TYPE PHOTO``
     - Photo content. The content is derived from digital still pictures.
       The content should be passed through with minimal scaling and
   picture enhancements.
* - ``V4L2_DV_IT_CONTENT_TYPE_CINEMA``
      - Cinema content.
   * - ``V4L2 DV IT CONTENT TYPE GAME``
      - Game content. Audio and video latency should be minimized.
    * - ``V4L2_DV_IT_CONTENT_TYPE NO ITC`
     - No IT Content information is available and the ITC bit in the AVI
       InfoFrame is set to 0.
```

```
V4L2_CID_DV_RX_POWER_PRESENT (bitmask)
```

Detects whether the receiver receives power from the source (e.g. HDMI carries 5V on one of the pins). This is often used to power an eeprom which contains EDID information, such that the source can read the EDID even if the sink is in standby/power off. Each bit corresponds to an input pad on the receiver. If an input pad cannot detect whether power is present, then the bit for that pad will be 0. This read-only control is applicable to DVI-D, HDMI and DisplayPort connectors.

```
V4L2_CID_DV_RX_RGB_RANGE
```

(enum)
enum v412 dv rgb range -

Select the quantization range for RGB input. V4L2_DV_RANGE_AUTO follows the RGB quantization range specified in the standard for the video interface (ie. ref. cea861 for HDMI). V4L2_DV_RANGE_LIMITED and V4L2_DV_RANGE_FULL override the standard to be compatible with sources that have not implemented the standard correctly (unfortunately quite common for HDMI and DVI-D). Full range allows all possible values to be used whereas limited range sets the range to (16 << (N-8)) - (235 << (N-8)) where N is the number of bits per component. This control is applicable to VGA, DVI-A/D, HDMI and DisplayPort connectors.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master]
[Documentation] [userspace-api] [media] [v41] ext-ctrls-dv.rst, line 139); backlink

Unknown interpreted text role "ref".

```
V4L2_CID_DV_RX_IT_CONTENT_TYPE

(enum)

enum v4l2 dv it content type -
```

Reads the IT Content Type of the received video. This information is sent over HDMI and DisplayPort connectors as part of the AVI InfoFrame. The term 'IT Content' is used for content that originates from a computer as opposed to content from a TV broadcast or an analog source. See V4L2 CID DV TX IT CONTENT TYPE for the available content types.