## dvb-usb-dvbsky cards list

Unknown directive type "tabularcolumns".

```
.. tabularcolumns:: |p{7.0cm}|p{10.5cm}|
```

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\admin-guide\media\(linux-master)\((Documentation\) (admin-guide)\((media\)) dvb-usb-dvbsky-cardlist.rst, line 8)

Unknown directive type "flat-table".

- 0ccd:0105
\* - Terratec H7 Rev.4
- 0ccd:10a5

```
.. flat-table::
  :header-rows: 1
  :widths: 7 13
  :stub-columns: 0
  * - Card name
    - USB IDs
   * - DVBSky S960/S860
    - 0572:6831
   * - DVBSky S960CI
    - 0572:960c
  * - DVBSky T330
    - 0572:0320
   * - DVBSky T680CI
    - 0572:680c
  * - MyGica Mini DVB-(T/T2/C) USB Stick T230
    - 0572:c688
   * - MyGica Mini DVB-(T/T2/C) USB Stick T230C
     - 0572:c689
   * - MyGica Mini DVB-(T/T2/C) USB Stick T230C Lite
     - 0572:c699
   * - MyGica Mini DVB-(T/T2/C) USB Stick T230C v2
    - 0572:c68a
   * - TechnoTrend TT-connect CT2-4650 CI
    - 0b48:3012
  * - TechnoTrend TT-connect CT2-4650 CI v1.1
     - 0b48:3015
   * - TechnoTrend TT-connect S2-4650 CI
    - 0b48:3017
   * - TechnoTrend TVStick CT2-4400
    - 0b48:3014
   * - Terratec Cinergy S2 Rev.4
```