VIDEO CLEAR BUFFER

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\[linux-master][drivers][staging][media]
[av7110]video-clear-buffer.rst, line 2)
Unknown directive type "cnamespace".
.. c:namespace:: DTV.video
```

Name

VIDEO_CLEAR_BUFFER

```
Attention!
```

This ioctl is deprecated.

Synopsis

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\[linux-master][drivers][staging][media]
[av7110]video-clear-buffer.rst, line 20)
Unknown directive type "c:macro".
.. c:macro:: VIDEO_CLEAR_BUFFER
```

int ioctl(fd, VIDEO CLEAR BUFFER)

Arguments

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-
master\drivers\staging\media\av7110\[linux-master][drivers][staging][media]
[av7110]video-clear-buffer.rst, line 27)

Unknown directive type "flat-table".

.. flat-table::
    :header-rows: 0
    :stub-columns: 0

- .. row 1

- int fd

- File descriptor returned by a previous call to open().

- .. row 2

- int request

- Equals VIDEO_CLEAR_BUFFER for this command.
```

Description

This joctl call clears all video buffers in the driver and in the decoder hardware.

Return Value

On success 0 is returned, on error -1 and the errno variable is set appropriately. The generic error codes are described at the ref. Generic Error Codes <gen-errors>` chapter.

 $System\,Message:\,ERROR/3\,(\texttt{D:}\nonline) - resources \verb|\sample-onboarding-resources| linux-resources \verb|\sample-onboarding-resources| linux-resources | resources| linux-resources| linux-resourc$

 $\label{linux-master} $$\max \operatorname{\operatorname{linux-master}} [drivers] [staging] [media] $$ [av7110] video-clear-buffer.rst, $$\lim 52); $$backlink$$$

Unknown interpreted text role 'ref'.