## Linux 2.6.x on MPC52xx family

For the latest info, go to https://www.246tNt.com/mpc52xx/

To compile/use:

• U-Boot:

```
# <edit Makefile to set ARCH=ppc & CROSS_COMPILE=... ( also EXTRAVERSION
    if you wish to ).
# make lite5200_defconfig
# make uImage

then, on U-boot:
=> tftpboot 200000 uImage
=> tftpboot 400000 pRamdisk
=> bootm 200000 400000
ug:
```

• DBug:

```
# <edit Makefile to set ARCH=ppc & CROSS_COMPILE=... ( also EXTRAVERSION
   if you wish to ).
# make lite5200_defconfig
# cp your_initrd.gz arch/ppc/boot/images/ramdisk.image.gz
# make zImage.initrd
# make
then in DBug:
DBug> dn -i zImage.initrd.lite5200
```

## Some remarks:

- The port is named mpc52xxx, and config options are PPC\_MPC52xx. The MGT5100 is not supported, and I'm not sure anyone is interested in working on it so. I didn't took 5xxx because there's apparently a lot of 5xxx that have nothing to do with the MPC5200. I also included the 'MPC' for the same reason.
- Of course, I inspired myself from the 2.4 port. If you think I forgot to mention you/your company in the copyright of some code, I'll correct it ASAP.