AUDIO_CHANNEL_SELECT

Name

AUDIO_CHANNEL_SELECT

> **Attention!**
>
> This ioctl is deprecated

Synopsis

```
int ioctl(int fd, AUDIO_CHANNEL_SELECT, struct audio_channel_select *select)
```

Arguments

Description

This ioctl is for Digital TV devices only. To control a V4L2 decoder use the V4L2 `V4L2_CID_MPEG_AUDIO_DEC_PLAYBACK` control instead.

This ioctl call asks the Audio Device to select the requested channel if possible.

Return Value

On success 0 is returned, on error -1 and the `errno` variable is set appropriately. The generic error codes are described at the

:ref:`Generic Error Codes <gen-errors>` chapter.

> **System Message: ERROR/3** (`D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\[linux-master][drivers][staging][media][av7110]audio-channel-select.rst`, **line 55**); *backlink*
>
> Unknown interpreted text role "ref".

:ref:`Generic Error Codes <gen-errors>` chapter.

System Message: ERROR/3 (`D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\[linux-master][drivers][staging][media][av7110]audio-channel-select.rst`, **line 55**); *backlink*

Unknown interpreted text role "ref".