AUDIO SET STREAMTYPE

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-
master\drivers\staging\media\av7110\((linux-master)\) (drivers) (staging) (media)
(av7110) audio-set-streamtype.rst, line 2)
Unknown directive type "c:namespace".
... c:namespace:: DTV.audio
```

Name

AUDIO_SET_STREAMTYPE

```
Attention!
```

This ioctl is deprecated

Synopsis

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\(linux-master)\(drivers\) (staging) (media) (av7110) audio-set-streamtype.rst, line 20)
Unknown directive type "cmacro".
.. c:macro:: AUDIO_SET_STREAMTYPE
```

int ioctl(fd, AUDIO SET STREAMTYPE, int type)

Arguments

Description

This is useful if the stream offers several audio sub-streams like LPCM and AC3.

Return Value

On success 0 is returned, on error -1 and the errno variable is set appropriately. The generic error codes are described at the ref. Generic Error Codes <gen-errors>` chapter.

 $System \, Message: ERROR/3 \, (\color="linux-master") \, (\color="linux$

Unknown interpreted text role 'ref'.

```
System\ Message: ERROR/3\ (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\ (linux-master)\ (drivers)\ (staging)\ (media)\ (av7110)\ audio-set-streamtype.rst, line\ 58)
```

Unknown directive type "flat-table".

```
.. flat-table::
    :header-rows: 0
    :stub-columns: 0

-    .. row 1
    - ``EINVAL``
    - type is not a valid or supported stream type.
```