AUDIO SET AV SYNC

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-
master\drivers\staging\media\av7110\((linux-master)\) (drivers) (staging) (media)
(av7110) audio-set-av-sync.rst, line 2)
Unknown directive type "cnamespace".
.. c:namespace:: DTV.audio
```

Name

AUDIO_SET_AV_SYNC

```
Attention!
```

This ioctl is deprecated

Synopsis

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\((linux-master)\) (drivers) (staging) (media) (av7110) audio-set-av-sync.rst, line 20)

Unknown directive type "c:macro".

.. c:macro:: AUDIO_SET_AV_SYNC
```

int ioctl(int fd, AUDIO SET AV SYNC, boolean state)

Arguments

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-
master\drivers\staging\media\av7110\(linux-master\) (drivers) (staging) (media)
(av7110) audio-set-av-sync.rst, line 27)

Unknown directive type "flat-table".

.. flat-table::
    :header-rows: 0
    :stub-columns: 0

-
    - int fd
- File descriptor returned by a previous call to open().

-
    - boolean state
- Tells the Digital TV subsystem if A/V synchronization shall be ON or OFF.
    TRUE: AV-sync ON
    FALSE: AV-sync OFF
```

Description

This ioctl call asks the Audio Device to turn ON or OFF A/V synchronization.

Return Value

On success 0 is returned, on error -1 and the error variable is set appropriately. The generic error codes are described at the

rref: Generic Error Codes <gen-errors>' chapter.

 $System \, Message: ERROR/3 \, (\texttt{D:\noboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\ (linux-master) \, (drivers) \, (staging) \, (media) \, (av7110) \, audio-set-av-sync.rst, \, line \, 56); \, backlink$

Unknown interpreted text role 'ref'.