Querying frontend information

Usually, the first thing to do when the frontend is opened is to check the frontend capabilities. This is done using ref:FE_GET_INFO. This ioctl will enumerate the Digital TV API version and other characteristics about the frontend, and can be opened either in read only or read/write mode.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\(linux-master) (Documentation) (userspace-api) (media) (dvb) query-dvb-frontend-info.rst, line 9); backlink

Unknown interpreted text role 'ref'.